

PROFINET

User Manual



Contents

| | |
|---|----|
| Preface | 3 |
| Terms of use | 4 |
| Revision overview..... | 5 |
| Connection diagram | 6 |
| Applicable for: LA14, LA25, LA21, LA33, LA36, LA37, LA73, LA76 and LA77 | 6 |
| Applicable for: LC3 IC..... | 7 |
| I/O specifications..... | 8 |
| Protection..... | 9 |
| Current limit..... | 9 |
| Parallel..... | 9 |
| Getting started | 11 |
| PROFINET GSDML..... | 11 |
| Power supply..... | 11 |
| Parameters to be verified by Actuator Connect™ | 13 |
| Command examples | 14 |
| General run prerequisites..... | 14 |
| Run the actuator outwards | 15 |
| Run the actuator to target position (150 mm)..... | 16 |
| Overcurrent state..... | 17 |
| Clear error | 17 |
| Process data..... | 18 |
| Process Data Out (Command)..... | 18 |
| Process Data In (Feedback)..... | 19 |
| Process Data In (Parallel Feedback)..... | 21 |
| Data records | 22 |
| Configuration..... | 22 |
| Diagnostics | 23 |
| Reason for last stop definition..... | 26 |
| FAQ | 27 |
| Error codes | 28 |
| Parallel error codes..... | 30 |
| Contacts..... | 32 |

Preface

Dear User,

We are delighted that you have chosen a LINAK® product.

LINAK systems are high-tech products based on many years of experience in the manufacture and development of actuators, lifting columns, desk frames, electric control boxes, controls, batteries, accessories and chargers.

This User Manual does not address the end user. It is intended as a source of information for the equipment or system manufacturer only, and it will tell you how to install, use and maintain your LINAK electronics. The manufacturer of the end product has the responsibility to provide a User Manual, where relevant safety information from this manual is passed on to the end user.

We are convinced that your LINAK product/system will give you many years of problem-free operation.

Before our products leave the factory, they undergo both function and quality testing. Should you, nevertheless, experience problems with your product/system, you are always welcome to contact your supplier.

LINAK subsidiaries and some distributors situated all over the world have authorised service centres, which are always ready to help you. Locate your local contact information on the back page.

LINAK provides a warranty on all products. (See warranty section).

This warranty, however, is subject to correct use in accordance with the specifications, maintenance being done correctly, and any repairs being carried out at a service centre, which is authorised to repair LINAK products.

Changes in installation and use of LINAK systems can affect their operation and durability. The products may only be opened by authorised personnel.

This User Manual has been written based on the present technical knowledge. LINAK reserves the right to carry out technical modifications and keeps the associated information updated.

LINAK A/S

Terms of use

LINAK® takes great care in providing accurate and up-to-date information on its products. However, the user is responsible for determining the suitability of LINAK products for a specific application.

Due to continual development, LINAK products are subject to frequent modifications and changes. LINAK reserves the rights to conduct modifications, updates, and changes without any prior notice. For the same reason, LINAK cannot guarantee the correctness and actual status of imprinted information on its products.

LINAK uses its best efforts to fulfil orders. However, for the reasons mentioned above, LINAK cannot guarantee availability of any particular product at any given time. LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or in other written material created and produced by LINAK, LINAK subsidiaries, or LINAK affiliates.

All sales are subject to the 'Standard Terms of Sale and Delivery for LINAK A/S' available on LINAK websites.

LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.

Revision overview

Edition D

| | |
|--|-----------------------|
| Connection diagram for linear actuators updated | Page 6 |
| Connection diagram for LC3 IC updated | Page 7 |
| I/O specifications updated | Page 8 |
| Voltages removed from illustrations | Page 10 |
| Information about changeable IP address via TIA portal added | Page 13 |
| Warning against the public internet added | Page 13 |
| 'Normal' changed to 'Nominal' | Page 14 |
| 'RunCommand' changed to 'Command' | Page 15-17 |
| 'Clear error' table added | Page 17 |
| 'Error Flags' changed to 'Status Flags' | Page 19 |
| b7 in 'Process Data In (Feedback)' changed | Page 19 |
| b3-b15 in 'Process Data In (Parallel Feedback)' changed | Page 21 |
| 'Diagnostics' table updated | Page 23 |
| 2047 corrected to 2048 | Page 26 |
| FAQ updated | Page 27 |
| Parallel error code 25 - Position lost description updated | Page 31 |
| 'Slave' changed to 'Follower' | All over the document |

Edition C

| | |
|--|-----------------------|
| Plug type added to plug view | Page 6 |
| Item number for cable kit added | Page 6-7 |
| 'Current limit' section added | Page 9 |
| Parallel 'Check power supply' updated | Page 9 |
| PROFINET GDSML file information added | Page 11 |
| 'Process data' section updated | Page 18-22 |
| 'Data records' section updated | Page 22-25 |
| 'Reason for Last Stop' table updated | Page 26 |
| Error codes updated | Page 28-29 |
| Parallel error codes updated | Page 30-31 |
| 'Soft Start' changed to 'Ramp Up' + 'Soft Stop' changed to 'Ramp Down' | All over the document |
| LA14, LA25, and LA21 added | All over the document |
| Identical cells in tables merged | All over the document |
| 'Read' and 'Write' changed to 'R' and 'W' | All over the document |
| Profinet™ changed to PROFINET | All over the document |

Edition B

| | |
|---|------------|
| LA33 added | Page 6 |
| 'Option 1 - A simple parallel setup' illustration updated | Page 9 |
| 'Command examples' section updated | Page 14-17 |
| 'Process data' section added | Page 18-23 |
| Data records, Configuration and Diagnostics removed | |

Edition A

New document

Connection diagram

Applicable for: LA14, LA25, LA21, LA33, LA36, LA37, LA73, LA76 and LA77

BROWN 24/48 V DC

BLUE GND




4 Split power supply V DC

1 Extends the actuator

2 Retracts the actuator

3 Parallel data +

5 Parallel data -




M12
A-Code male

1 ETH_TX+

2 ETH_RX+

3 ETH_TX-

4 ETH_RX-



M12
D-Code female

Connection diagram

Applicable for: LC3 IC

BROWN 24/48 V DC

BLUE GND



ORANGE Split power supply V DC

RED Extends the actuator

BLACK Retracts the actuator

VIOLET Parallel data +


WHITE Parallel data -

YELLOW Not to be connected

GREEN Not to be connected

LIGHT BLUE Not to be connected

GREY Not to be connected




Molex mini-fit
12-pin

1 ETH_TX+

3 ETH_RX+


2 ETH_TX-

6 ETH_RX-



RJ45

I/O specifications

| Input/Output | | Specification | Comments |
|--------------|----------------|---|--|
| Description | | The physical layer conforms to the IEEE 802.3-2018 standard with communication speeds of 10 Mbps and 100 Mbps, respectively. Cable length is reduced to = 100 m without repeater, as determined by IEEE 802.3-2018. |  |
| Brown | | Connect Brown to positive 24/48 V DC | <p>Note:</p> <p>Do not change the power supply polarity on the Brown and Blue wires!</p> <p>Only for powering the motor driver module.</p> <p>Power supply GND is electrically connected to the housing through a capacitor and resistor in parallel.</p> |
| Blue | | Connect Blue to negative GND | |
| PIN out | | Data cable M12 - 5-pin male OR Molex mini-fit - 12-pin | |
| M12 | Molex mini-fit | | |
| Pin 4 | Orange | Split power supply V DC | <p>Split power supply:</p> <p>24 V DC with ≈ 28 mA current consumption. 48 V DC with ≈ 16 mA current consumption.</p> <p>The split power supply uses the common GND from the power supply (Blue).</p> <p>Split power supply is only for powering the communication of the integrated controller.</p> |
| Pin 1 | Red | Extends the actuator | <p>The signal becomes active at:</p> $V_{IN} > 67\%$ of V DC <p>The signal becomes inactive at:</p> $V_{IN} < 33\%$ of V DC <p>Input current: 10 mA</p> |
| Pin 2 | Black | Retracts the actuator | |
| Pin 3 | Violet | Parallel data + | <p>The Parallel drive function will support up to 8 actuators running simultaneously.</p> <p>It is possible to run Parallel with a main power supply or separate power supplies.</p> |
| Pin 5 | White | Parallel data - | |
| PIN out | | Data cable M12 - 4-pin female OR RJ45 | |
| M12 | RJ45 | | |
| Pin 1 | Pin 1 | ETH_TX+ | |
| Pin 2 | Pin 3 | ETH_RX+ | |
| Pin 3 | Pin 2 | ETH_TX- | |
| Pin 4 | Pin 6 | ETH_RX- | |

Protection

Current limit

Current limits can be configured to avoid crushing when meeting an obstacle. These values can be adjusted according to your preferences. Use default values or fine-tune your current limits with 0.25 A/bit.

It is important to note that current limits should not be relied upon as a general stop function, as this will potentially stress the mechanics and could lead to long-term damage to the actuator.

Furthermore, current limits do not correlate directly with the actuator's load curves, meaning they should not be used as indicators of load. Various tolerances in components such as the spindle, nut, and gears can also affect the current consumption of the actuator. Operation in environments with temperatures below 0°C will also increase the current consumption. When temperature drops below 0°C, the default current limit will change to a higher value.

Actuator specific current limit values (above and below reference temp.) can be found in the respective actuator user manual or in the Actuator Connect service tool under 'Protection'.

Parallel


The industrial LINAK® actuators can be ordered with parallel functionality. If this feature is enabled, it is possible to run up to 8 actuators in a parallel system with just one actuator occupying an Ethernet port connection. The system works as a critical parallel, meaning that all actuators must be present in the system and have the exact same configuration (both mechanical and software functionality).

Below is a checklist to ensure that the system operates as intended:

| Action | Description |
|--------------------------------------|---|
| Set up parallel in Actuator Connect™ | Each actuator must be configured to operate in parallel (2-8 actuators). This can be set up using the Actuator Connect tool. <i>Please note: In some cases this is pre-configured from factory.</i> |
| Wire up the system | The actuators feature internal communication for parallel synchronisation and error codes. |
| Check cable lengths | Keep the total length of the communication line below 40 meters to avoid communication dropouts. In a parallel system with 8 actuators this would result in signal cable lengths of <5 metres. |
| Check power supply | It is also possible to use two or more separate power supplies in parallel under the condition that they have the same voltage and wattage output. It is essential that all power supplies share a common ground connection (Blue wire). Please respect actuator specifications regarding voltage level and current consumption! |

Parallel


Option 1 - A simple parallel setup



In a simple parallel setup there is only one actuator connected to the network. This actuator receives run commands and shares data with the controller. The remaining actuators in the system are only connected to internal parallel communication. This way, the internal communication ensures that the system operates in parallel and stops in case of an obstacle, or when other errors occur on one of the actuators.

The actuators share simple error messages with the master, which can be distributed via the network.

Option 2 - Bus communication on all actuators



If there is a need for e.g. monitoring the real-time data of each actuator, it is possible to connect all actuators as nodes to the network. This will provide comprehensive usage data, which can be used to enhance performance in the application. Similar to option 1, this requires that all actuators are connected to internal parallel communication.

It is also possible to use two separate power supplies in parallel under the condition that they have the same voltage and wattage output. It is essential that both power supplies share a common ground connection (Blue wire).

Getting started

This section further describes how to communicate with LINAK® PROFINET actuators and contains examples of typical user scenarios and application solutions. All examples include references to registers which are further described in detail below.

The LINAK actuator is a PROFINET input and output peripheral device. It is integrated into a PROFINET network as a follower. This means that the actuator uses data from the master on the PROFINET (output data) and also produces data for the PROFINET itself (input data).

PROFINET defines real-time communication for the fast transmission of process data.

PROFINET GSDML

A GSDML file defines the specifications and functionality of a PROFINET device, enabling engineering tools to integrate and configure it within a network. It includes essential communication details such as device identification, vendor name, model number, parameters, and even the device image. By importing this file, engineers can seamlessly add the device to their project, ensuring compatibility and proper operation with other components, regardless of the manufacturer.

The LINAK_GSDML file is available for download by using the following link: [LINAK PROFINET GSDML.zip](#)

Power supply

PROFINET actuators are available with the following supply voltage range: 24 and 48 V DC. The accepted supply voltage range is specified for the version as shown below:

| Supply voltage | Function | Voltage range | | |
|----------------|------------------------|-----------------|------------------|------------------|
| | | V _{IN} | V _{TYP} | V _{MAX} |
| 24 V | Motor | 18 V | 24 V | 32 V |
| | PROFINET communication | 10 V | 24 V | 39 V |
| 48 V | Motor | 36 V | 48 V | 58 V |
| | PROFINET communication | 10 V | 48 V | 60 V |



For more information about wiring/connector, please see the connection diagram.


Configuration

Before being integrated into a PROFINET system, a few of the actuator parameters must be checked and eventually changed. This preparation is done via the use of the configuration tool Actuator Connect™ and guarantees that the actuator is able to execute basic functionality.

Further fine-tuning may be required to fulfil system or application requirements. Via this tool it is also possible to access historical usage data and real-time monitoring.


Valid for LA14 and LA25:

A separate configuration cable kit (item no. 0257901 = straight Y-cable + USB2LIN) is required to use Actuator Connect™ on a PC. This cable must be connected to the 9-pin connector on the actuator side. On the opposite side, power must be applied to the flying leads, and the USB connector must be inserted into your PC.



Valid for LA21, LA33, LA36, LA37, LA73, LA76, LA77, and LC3 IC:

A separate configuration cable (item no. 0367996) is required to use Actuator Connect on a PC. This cable must be connected to the 6-pin and 9-pin connector on the actuator side. On the opposite side, power must be applied to the Brown (V DC) and Blue (GND) wires, and the USB connector must be inserted into your PC.



For more information about wiring/connector, please see the connection diagram.

Parameters to be verified by Actuator Connect™

| Parameters | Description |
|-------------|---|
| Device name | Assign device name. |
| DHCP | DHCP is a client/server protocol that automatically provides an IP address. If enabled: below parameters are not configurable |
| IP address | Set the device IP address to a unique address in the network. 192.168.1.10 (default) |
| Subnet mask | Set the subnet mask. 255.255.255.0 (default) |
| Gateway | Set the gateway. 192.168.1.1 (default) |

The device's IP address can also be configured or modified using Siemens engineering tools such as TIA Portal or PRONETA. Both tools allow you to assign network parameters and update the device's IP settings during commissioning or maintenance. Ensure that any changes made to the IP address align with your system's network design and do not result in address conflicts.



Users are strongly advised against configuring their assets directly to the public internet. By taking this precautionary measure, the risk of unauthorized and malicious cyber activities from external threats is significantly reduced.

Command examples

Before the actuator can engage movement, some general prerequisites must be fulfilled. Timing (e.g. when the actuator is still moving), environmental conditions and errors might mean that the actuator is in a state where further operation is not possible.

General run prerequisites

| Step | Read/Write | Process data* | Action |
|------|------------|------------------------------|--|
| 1 | W | Command Byte 0 Byte 1 | "Position" must be set to = 64259 [0xFB03] for 'Stop'. To prevent unintended movement, it is required to send a 'Stop' command before running the actuator. |
| 2 | R | Feedback Byte 6 Byte 7 | "Error Code" must be = 0 [0x00] |
| 3 | | Feedback Byte 4 Byte 5 | "Status Flags" bit 2 (Overcurrent) must be = 0 |
| 4 | | Feedback Byte 4 Byte 5 | "Status Flags" bit 5 (Heartbeat needed) must be = 0 |
| 5 | | Feedback Byte 4 Byte 5 | "Status Flags" bit 6 (Actuator is running outside nominal conditions) must be = 0 |

* Feedback = Process Data In / Command = Process Data Out

Run the actuator outwards

| Step | Read/ Write | Process data* | Action |
|------|----------------|------------------------------|---|
| 1 | | - | Check that general run prerequisites are fulfilled. |
| 2 | W | Command Byte 2 Byte 3 | "Current" must be set to a value. 0-250 [0x00-FA] = Current limit 0.25 A/bit 251 [0xFB] = Default current limit set via Actuator Connect™ 252-255 [0xFC-FF] = Reserved |
| 3 | | Command Byte 4 Byte 5 | "Speed" must be set to a value. 0-200 [0x00-FA] = Speed 0.5% /bit 201-250 [0xC9-FA] = 100% speed 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 4 | | Command Byte 6 Byte 7 | "Ramp Up" must be set to a value. 0-200 [0x00-FA] = Start ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 5 | | Command Byte 8 Byte 9 | "Ramp Down" must be set to a value. 0-200 [0x00-FA] = Stop ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 6 | | Command Byte 0 Byte 1 | "Position" must be set to = 64257 [0xFB01] for 'Run out.' |
| 7** | R | Feedback Byte 4 Byte 5 | "Status Flags" bit 3 and bit 1 change to 1 to indicate that: Bit 3 = Actuator is running out Bit 1 = Endstop reached out |

* Feedback = Process Data In / Command = Process Data Out

** Optional

Run the actuator to target position (150 mm)

| Step | Read/Write | Process data* | Action |
|------|------------|------------------------------|---|
| 1 | | - | Check that general run prerequisites are fulfilled. |
| 2 | W | Command Byte 2 Byte 3 | "Current" must be set to a value. 0-250 [0x00-FA] = Current limit 0.25 A/bit 251 [0xFB] = Default current limit set via Actuator Connect™ 252-255 [0xFC-FF] = Reserved |
| 3 | | Command Byte 4 Byte 5 | "Speed" must be set to a value. 0-200 [0x00-FA] = Speed 0.5% /bit 201-250 [0xC9-FA] = 100% speed 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 4 | | Command Byte 6 Byte 7 | "Ramp Up" must be set to a value. 0-200 [0x00-FA] = Start ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 5 | | Command Byte 8 Byte 9 | "Ramp Down" must be set to a value. 0-200 [0x00-FA] = Stop ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 6 | | Command Byte 0 Byte 1 | "Position" must be set to = 1500 [0x05DC] for 'Run to Target Position 150 mm' |
| 7** | R | Feedback Byte 4 Byte 5 | "Status Flags" bit 3 or bit 4 change to 1 to indicate that either: Bit 3 = Actuator is running out Bit 1 = Actuator is running in |

* Feedback = Process Data In / Command = Process Data Out

** Optional

Overcurrent state

If an overcurrent occurs, the actuator will be stopped and blocked in that direction until an activation in the opposite direction has been made or the system has been re-powered.

| Step | Read/Write | Process data* | Action |
|------|------------|------------------------------|--|
| 1 | R | Feedback Byte 4 Byte 5 | Confirm that "Status Flags" bit 2 is = 1 for 'Overcurrent' |
| 2 | W | Command Byte 0 Byte 1 | "Position" must be set to run in the opposite direction of the blockage Set to = 64257 [0xFB01] for 'Run out' or Set to = 64258 [0xFB02] for 'Run in' |
| 3** | R | Feedback Byte 4 Byte 5 | "Status Flags" bits change to 1 to indicate that either: Bit 3 = Actuator is running out Bit 4 = Actuator is running in Bit 1 = Endstop reached out Bit 0 = Endstop reached in |

* Feedback = Process Data In / Command = Process Data Out

** Optional

Clear error

If an error occurs, the actuator will be stopped, and normal movement will not be possible.

| Step | Read/Write | Process data* | Action |
|------|------------|-----------------|---|
| 1 | R | PDI Byte 6-7 | Confirm that "Error Code" is not = 0 |
| 2 | W | PDO Byte 0-1 | "Position" set to = 64256 (Clear Error Codes) |
| 3 | R | PDI Byte 6-7 | Confirm that "Error Code" is = 0 If "Error Code" is not = 0, then correct the error in the system and repeat step 2. |

* PDI = Process Data In / PDO = Process Data Out

Process data

In a PROFINET IO system, process data consists of cyclically exchanged data between an IO Controller (such as a PLC) and an IO Device (field device).

This input or output data is stored in the controller's process image and used by its application program to monitor and control processes.

Process Data Out (Command)

| Command Module ID 48 SLOT 1 Real-time cyclic data exchanged | | | | | | | | | |
|---|--------|---------|--------|--------|--------|---------------|--------|----------|-----------------|
| Byte 9 [MSB] | Byte 8 | Byte 7 | Byte 6 | Byte 5 | Byte 4 | Byte 3 | Byte 2 | Byte 1 | Byte 0 [LSB] |
| Ramp Down | | Ramp Up | | Speed | | Current Limit | | Position | |

| Module ID 48 SLOT 1 | | | | | |
|---------------------|---------------|-----------|---------|--|-------------|
| Byte(s) | Command | Data type | Details | Description | Scaling |
| Byte 0-1 | Position | UINT16 | 0-64255 | Run to position | 0.1 mm /bit |
| | | | 64256 | Clear Error Codes (see Process Data In Byte 6 and 7) | |
| | | | 64257 | Run out | |
| | | | 64258 | Run in | |
| | | | 64259 | Stop | |
| | | | 64260 | Recovery run out | |
| | | | 64261 | Recovery run in | |
| Byte 2-3 | Current Limit | UINT16 | 0-250 | Maximum current limit | 0.25 A /bit |
| | | | 251 | Default current limit | |
| | | | 252-255 | Invalid value, actuator will not run | |
| Byte 4-5 | Speed | UINT16 | 0-200 | Speed | 0.5% /bit |
| | | | 201-250 | 100% speed | |
| | | | 251 | Default speed | |
| | | | 252-255 | Invalid value, actuator will not run | |
| Byte 6-7 | Ramp Up | UINT16 | 0-250 | Ramp up time | 0.05 s /bit |
| | | | 251 | Default ramp up value | |
| | | | 252-255 | Invalid value, actuator will not run | |
| Byte 8-9 | Ramp Down | UINT16 | 0-250 | Ramp down time | 0.05 s /bit |
| | | | 251 | Default ramp down value | |
| | | | 252-255 | Invalid value, actuator will not run | |

Process Data In (Feedback)

| Feedback Module ID 49 (0x31) SLOT 2 Real-time cyclic data exchanged | | | | | | | | | | | |
|---|---------|--------|--------|------------|--------|--------------|--------|--------------|--------|----------|--------------|
| Byte 11 | Byte 10 | Byte 9 | Byte 8 | Byte 7 | Byte 6 | Byte 5 | Byte 4 | Byte 3 | Byte 2 | Byte 1 | Byte 0 [LSB] |
| AUX Inputs | | Speed | | Error Code | | Status Flags | | Current Draw | | Position | |

| Module ID 49 SLOT 2 | | | | | |
|---------------------|--------------|-----------|-------------|--|--|
| Byte(s) | Command | Data type | Details | Description | Scaling |
| Byte 0-1 | Position | UINT16 | 0-64255 | Position of the actuator | 0.1 mm /bit |
| | | | 64256-65023 | Reserved | |
| | | | 65024 | Position lost | |
| | | | 65025-65535 | Reserved | |
| Byte 2-3 | Current Draw | UINT16 | 0 | Not running | 0.25 A /bit |
| | | | 1-250 | Motor current draw | |
| | | | 251-253 | Reserved | |
| | | | 254 | Fault in current measurement circuit | |
| | | | 255 | Reserved | |
| Byte 4-5 | Status Flags | UINT16 | b0 | Endstop reached in | Bit-independent status indicators |
| | | | b1 | Endstop reached out | |
| | | | b2 | Overcurrent | |
| | | | b3 | Running out | |
| | | | b4 | Running in | |
| | | | b5 | Communication heartbeat needed | |
| | | | b6 | Actuator is running outside nominal conditions | |
| | | | b7 | Reserved. Always high | |
| | | | b8-b15 | Reserved | |
| Byte 6-7 | Error Code* | UINT16 | 0 | No error detected | 8-bit error code showing the current active error with the highest priority only |
| | | | 1 | Power on block state | |
| | | | 2 | Position sensor | |
| | | | 3 | Overvoltage | |
| | | | 4 | Undervoltage | |
| | | | 5 | Communication sync. | |
| | | | 6 | Endstop switch | |
| | | | 7 | Temperature | |

* See Error Code descriptions in section: [Error codes](#)

Process Data In (Feedback)

| Module ID 49 SLOT 2 | | | | | |
|---------------------|-------------|-----------|------------|--------------------------------------|--|
| Byte(s) | Command | Data type | Details | Description | Scaling |
| Byte 6-7 | Error Code* | UINT16 | 8 | Motor controller | 8-bit error code showing the current active error with the highest priority only |
| | | | 9 | Internal power supply | |
| | | | 10 | Internal current measurement | |
| | | | 11 | Parallel arbitration | |
| | | | 12 | Position not changing | |
| | | | 13 | Position initialisation not possible | |
| | | | 14 | Alone in parallel system | |
| | | | 15 | Incorrect number in parallel system | |
| | | | 16 | Hardware | |
| | | | 17 | BLDC motor | |
| | | | 18 | Parallel communication | |
| | | | 19 | Parallel running | |
| | | | 20 | Parallel setup stopped | |
| | | | 254 | Other internal error (Not specified) | |
| | | | 255 | Other external error (Not specified) | |
| Byte 8-9 | Speed | UINT16 | 0-4015 | Speed of actuator | 0.1 mm/s /bit |
| | | | 4016-65535 | Reserved | |
| Byte 10-11 | AUX Inputs | UINT16 | b0-b1 | Input 1 level | 1 bit/ 25% VCC |
| | | | b2-b3 | Input 2 level | |
| | | | b4-b15 | Reserved | |

* See Error Code descriptions in section: [Error codes](#)

Process Data In (Parallel Feedback)

| Parallel Feedback Module ID 49 SLOT 2 Real-time cyclic data exchanged | | | | | | | |
|---|---------|---------------------|---------|-----------------------|---------|---------|---------|
| Byte 19 | Byte 18 | Byte 17 | Byte 16 | Byte 15 | Byte 14 | Byte 13 | Byte 12 |
| Parallel Status Flags | | Parallel Error Code | | Parallel Error Source | | | |

| Module ID 49 SLOT 2 | | | | | |
|---------------------|-----------------------|-----------|-----------------|--|---|
| Byte(s) | Command | Data type | Details | Description | Scaling |
| Byte 12-15 | Parallel Error Source | UINT32 | 0 | No error detected | Decimal to IPv4 |
| | | | 1-4.294.967.295 | IP address of the actuator with highest priority error | |
| Byte 16-17 | Parallel Error Code* | UINT16 | 0 | No error detected | 8-bit error code indicating the current active error of highest priority on any actuator in the parallel system |
| | | | 1 | Current overload | |
| | | | 2 | Hardware | |
| | | | 3 | Temperature | |
| | | | 4 | Overvoltage | |
| | | | 5 | Undervoltage | |
| | | | 6 | Analogue input out of range error | |
| | | | 7 | Position not changing | |
| | | | 8 | Power on block state | |
| | | | 9 | Position initialisation not possible | |
| | | | 10 | Parallel start-up | |
| | | | 11 | Parallel running | |
| | | | 12 | BLDC motor | |
| | | | 13 | Endstop switch | |
| | | | 14 | Parallel communication | |
| | | | 15 | Parallel setup stopped | |
| | | | 24 | Other error | |
| 25 | Position lost | | | | |
| Byte 18-19 | Parallel Status Flags | UINT16 | b0 | Parallel endstop reached out | Bit-independent status indicators |
| | | | b1 | Parallel endstop reached in | |
| | | | b2 | Parallel running outside nominal conditions | |
| | | | b3-b15 | Reserved. Always high | |

* See Parallel Error Code descriptions in section: [Parallel error codes](#)

Data records

PROFINET data records are blocks of information in an IO device that can be read or written acyclically using RDREC and WRREC functions. They are used for tasks like device configuration, storing Identification and Maintenance (I&M) data, and providing diagnostics information.

These records are addressed by a combination of Slot, Subslot, and Index.

Configuration

| Configuration Module ID 50 SLOT 3 Acyclic data exchange | | | | | | |
|---|----------------------------|-----------|-----------|---|--------------------------|--------|
| Index | Parameter | Data type | Details | Description | Scaling | Access |
| 0 | Current Limit - Outwards | UINT8 | 0-255 | Works only when PDO "Current Limit" is 251* | 0.25 A/bit | R/W |
| 1 | Current Limit - Inwards | | | | | |
| 2 | Ramp Up - Outwards | UINT16 | 0-65535 | Works only when PDO "Ramp Up" is 251 | 1 ms/bit | R/W |
| 3 | Ramp Up - Inwards | | | | | |
| 4 | Ramp Down - Outwards | | | Works only when PDO "Ramp Down" is 251 | | |
| 5 | Ramp Down - Inwards | | | | | |
| 6 | Maximum Speed | UINT8 | 0-200 | Overrules PDO "Speed" | 0.5% /bit | R/W |
| | | | 201-255 | | 100% | |
| 7 | Virtual Endstop - Outwards | UINT16 | 0 | Sets the Virtual Endstop Outwards position | Disabled | R/W |
| | | | 1-699 | | Do NOT set below 70 mm** | |
| | | | 700-65535 | | 0.1 mm/bit | |
| 8 | Virtual Endstop - Inwards | UINT16 | 0 | Sets the Virtual Endstop Inwards position | Disabled | R/W |
| | | | 1-350 | | 0.1 mm/bit | |
| | | | 351-65535 | | Do NOT set above 35 mm** | |

* Actuator must power cycle before changes apply.

** Virtual limits set in the Initialisation zone will make Initialisation impossible.

Diagnostics

| Diagnostics Module ID 50 SLOT 3 Acyclic data exchange | | | | | | |
|---|---|-----------|---------|--------------------------------------|---------|--------|
| Index | Parameter | Data type | Details | Description | Scaling | Access |
| 9 | UIN | UINT32 | | Unique 8-digit identification number | | R |
| Software | | | | | | |
| 10 | Variant | UINT32 | | SWxxxxxxxVx-x | | R |
| 11 | Version Major | | | SWxxxxxxxVx-x | | |
| 12 | Version Minor | | | SWxxxxxxxVx-x | | |
| 13 | Config. Production Order Number | UINT32 | | Unique 8-digit identification number | | R |
| 14 | Production Date | | | yyyymmdd | | |
| 15 | Max. Current Seen | UINT8 | | 0.25 A/bit | | |
| 16 | Max. FET Temperature Seen | | | 1°C /bit - 40°C | | |
| 17 | Max. Ambient Temperature Seen | | | | | |
| 18 | Min. Ambient Temperature Seen | | | | | |
| 19 | Total Current Usage | UINT32 | | 1 (Ampere*seconds)/bit | | |
| 20 | Total Runtime | | | 1 s/bit | | |
| Number of stops due to | | | | | | |
| 21 | Overtoltage | UINT8 | | Number of stops | | R |
| 22 | FET Overtemperature | | | | | |
| 23 | Ambient Overtemperature | | | | | |
| 24 | Undervoltage | | | | | |
| 25 | Hall Error | | | | | |
| 26 | Endstop Switch Error | | | | | |
| 27 | Default Current Limit Overloads - Out | | | | | |
| 28 | Default Current Limit Overloads - In | | | | | |

Diagnostics

| Diagnostics Module ID 50 SLOT 3 Acyclic data exchange | | | | | | |
|---|--------------------------------------|-----------|---------|--|---------|--------|
| Index | Parameter | Data type | Details | Description | Scaling | Access |
| Number of resettable stops due to | | | | | | |
| 29 | Custom Current Limit Overloads - Out | UINT8 | | Can be used to keep track of current overload stops from the last reset. Can only be set to 0. | | RW |
| 30 | Custom Current Limit Overloads - In | | | | | |
| Number of | | | | | | |
| 31 | Communication Errors | UINT16 | | Number of | | R |
| 32 | Endstop Reached - Out | UINT32 | | | | |
| 33 | Endstop Reached - In | | | | | |
| 34 | Starts - Out | | | | | |
| 35 | Starts - In | | | | | |
| 36 | Total Piston Distance Traveled | UINT32 | | 5 m/bit | | R |
| Reason for Last Stop – ID 0: See Reason for Last Stop definitions in section below | | | | | | |
| 37 | Reason | UINT16 | | Reason for stop | | R |
| 38 | Count | UINT8 | | Number of stops in a row | | |
| 39 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |
| Reason for Last Stop – ID 1: See Reason for Last Stop definitions in section below | | | | | | |
| 40 | Reason | UINT16 | | Reason for stop | | R |
| 41 | Count | UINT8 | | Number of stops in a row | | |
| 42 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |
| Reason for Last Stop – ID 2: See Reason for Last Stop definitions in section below | | | | | | |
| 43 | Reason | UINT16 | | Reason for stop | | R |
| 44 | Count | UINT8 | | Number of stops in a row | | |
| 45 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |
| Reason for Last Stop – ID 3: See Reason for Last Stop definitions in section below | | | | | | |
| 46 | Reason | UINT16 | | Reason for stop | | R |
| 47 | Count | UINT8 | | Number of stops in a row | | |
| 48 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |

Diagnostics

| Diagnostics Module ID 50 SLOT 3 Acyclic data exchange | | | | | | |
|---|--------------------------------|-----------|---------|--|---------|--------|
| Index | Parameter | Data type | Details | Description | Scaling | Access |
| Reason for Last Stop – ID 4: See Reason for Last Stop definitions in section below | | | | | | |
| 49 | Reason | UINT16 | | Reason for stop | | R |
| 50 | Count | UINT8 | | Number of stops in a row | | |
| 51 | Powered Time | UINT32 | | Powered time when the last stop occurred | 1 s/bit | |
| Reason for Last Stop – ID 4: See Reason for Last Stop definitions in section below | | | | | | |
| 52 | Total Corrected Distance | UINT32 | | 1 mm/bit | | R |
| 53 | FET Temperature | UINT8 | | 1°C /bit - 40°C | | |
| 54 | Ambient Temperature | | | | | |
| 55 | Number of Hall Shifts at Learn | UINT16 | | 0.1 mm/bit | | R |
| 56 | Zero Point Offset at Learn | | | | | |
| 57 | Production Order Number | UINT32 | | Unique 8-digit identification number | | |
| LINAK Special Functions | | | | | | |
| 58 | Functions | UINT8 | 0 | Reserved | | R/W |
| | | | 1 | Restart actuator | | |
| | | | 2-255 | Reserved | | |
| UIN in Parallel System | | | | | | |
| 59 | UIN 1 | UINT32 | | Sorted in descending order | | R |
| 60 | UIN 2 | | | | | |
| 61 | UIN 3 | | | | | |
| 62 | UIN 4 | | | | | |
| 63 | UIN 5 | | | | | |
| 64 | UIN 6 | | | | | |
| 65 | UIN 7 | | | | | |
| 66 | UIN 8 | | | | | |
| 67 | Powered Time | UINT32 | | 1 s/bit | | R |
| 68 | Remaining Life | UINT8 | 0-100 | Remaining life (Counting down) | 1% /bit | |
| | | | 101-249 | Reserved | | |
| | | | 250 | Remaining life not supported | | |
| | | | 251-255 | Reserved | | |

Reason for Last Stop definition

| Reason for last stop | Function | Description |
|----------------------|--|--|
| 1 | H-bridge fault | There is a hardware problem causing the system to malfunction or the gate driver to not respond correctly. |
| 2 | Overtemperature | The device or the surrounding temperature got too hot while it was running. |
| 4 | Undervoltage | The voltage dropped below the required level while it was running. |
| 8 | Overcurrent | Current consumption exceeded the limit, resulting in a time-out or an actuator stall. |
| 16 | SMPS fault | The 12 V and/or 5 V levels are not within the normal range. |
| 32 | Endstop fault | Both EOS switches were turned on at the same time while running. |
| 64 | Hall fault | One Hall sensor changed more than 10 times while the motor voltage was high, but the other sensor did not change. |
| 256 | Overvoltage | The voltage went too high while it was running, probably because of the braking. |
| 512 | Position not changing | Even though power is above the level needed for the motor to turn, the position doesn't change. |
| 1024 | Hardware fault | A hardware problem has occurred. Possible reasons might include issues with the gate driver, incorrect current measurements, or a malfunctioning motor sensor. |
| 2048 | Communication drop-out | The source of the request stopped, or the signal was lost. |
| 4096 | Change of interface | The actuator is connected to a more important system than the one that made the request. |
| 4097 | Parallel master detected a change in the number of connected followers | The parallel system stopped because a registered device disconnected, or a new device connected. |
| 4098 | Parallel master was stopped by a follower | A parallel master stopped running because a follower requested the master to hard stop. |
| 4099 | Parallel follower lost connection to master | A parallel follower stopped running because the connection to the master was lost. |
| 4100 | Parallel communication fault | An actuator in the parallel system stopped working because it had too many communication errors in a short time. |

FAQ

| Problem | Cause / Solution |
|---|---|
| Why is the actuator not running despite giving it a 'Run' command? | <ol style="list-style-type: none"> 1. Make sure that power is applied from the power supply. 2. Send a 'Clear error' 0xFB00 (64256) command before sending a 'Run' command. 3. Make sure that the configuration parameters Max. Speed 0x06, Current Limit Out 0x00 and Current Limit In 0x01 are not set to '0'. |
| Where can I find the latest GSDML file? | At LINAK.com |
| Why does the PLC show a reversed data order? | On most PLCs, the GSDML file will ensure the correct order of data input/output bytes according to the 'Process data' table. However, some controllers may reverse the data order. Please make sure the correct Most Significant Byte [MSB] and Least Significant Byte [LSB] are matching your configuration. If you experience maximum feedback data values (Position, Current and/or Speed), 0xFF (255) for byte data types and 0xFFFF (65535) for integer data types, the order is most likely reversed. |
| What is the highest priority process or parameter and diagnostic data? | Commonly referred to as cyclic and acyclic data. For example, current limit value in amps can be set in both cyclic and acyclic data. In this case, the lowest value determines when the actuator will stop. |
| <p>Is the data order of received "Feedback" correct?</p> <p>or</p> <p>Do I have a working connection?</p> | <p>If you are unsure whether you have a working connection or if your data order is correct, you can look for the Status Flags byte in the feedback data. The Status Flags byte will always have a value higher than "0", because bit 7 is always "1".</p> <p>Typically, the byte value will be "1000 0001" Binary or "81" Decimal, indication "Endstop reached".</p> <p>This value should show in byte 3 of received feedback bytes.</p> |

Error codes

All error codes apply to the entire TECHLINE® interface portfolio; some may not relate to your specific interface or product type.

| Error | Description |
|-------|---|
| 0 | No error detected No LINAK defined error detected. |
| 1 | Power on block state As a safety precaution to prevent unintentional movement at power-up, the actuator will not run until a 'Stop' command or 'Clear error' command has been sent. |
| 2 | Position sensor Position sensors are outside of expected operating range. Example: 10 pulses were reported on one Hall sensor and no Hall pulses on the other. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 3 | Overvoltage Input supply voltage is above operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits. |
| 4 | Undervoltage Input supply voltage is below operating voltage level. The error can only be cleared by sending a 'Clear error' command once the voltage is within the acceptable range. Consult the documentation for correct voltage levels. |
| 5 | Communication sync. Heartbeat from the master is not within the expected heartbeat interval. Consult the documentation for minimum requirements for heartbeat interval. |
| 6 | Endstop switch Endstop switches are behaving unexpectedly. Example: Both endstop switches have been activated simultaneously for more than 100 ms. Perform the initialisation process by running the actuator fully extended and retracted. |
| 7 | Temperature Internal actuator temperature is above operating limit. Consult the documentation for correct temperature levels. The error will automatically be cleared when the temperature is within operating limits. |
| 8 | Internal motor controller Internal motor controller hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 9 | Internal power supply The internal power supply is behaving unexpectedly. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 10 | Internal current measurement Internal current reference is outside the expected limits. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 11 | Parallel arbitration Start-up parallel configuration procedure in progress. |
| 12 | Position not changing Internal position sensor is behaving unexpectedly and motor might stall. Please check your application for blockage or other irregularities. If the error persists, contact LINAK or replace the product. |
| 13 | Position initialisation not possible Internal initialisation parameters missing. Contact LINAK. |

Error codes

| Error | Description |
|-------|--|
| 14 | Alone in parallel system Incorrect number of actuators in parallel system. |
| 15 | Incorrect number in parallel system Incorrect number of actuators in parallel system or wrongly configured. |
| 16 | Hardware There is an internal motor controller malfunction affecting the actuator's ability to operate correctly. Contact LINAK. |
| 17 | BLDC motor Position sensors are outside of expected operating range. Example: 10 pulses were reported on one Hall sensor and no Hall pulses on the other. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 18 | Parallel communication There are issues with the communication setup among the master and the follower devices. Make sure all cables are secured properly in the connectors. |
| 19 | Parallel running Parallel out of sync. |
| 20 | Parallel setup stopped The parallel master was stopped by a follower with some fault. To diagnose the specific issue, refer to the separate parallel feedback where the error codes from the followers can be read for more detailed information. |
| 254 | Other internal error (Not specified) Unspecified internal hardware/software error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 255 | Other external error (Not specified) Unspecified external hardware/software error. Please inspect your application for possible issues. Send 'Clear error' command to clear error. |

Parallel error codes

All error codes apply to the entire TECHLINE® interface portfolio; some may not relate to your specific interface or product type.

| Error | Description |
|-------|--|
| 0 | No error detected No LINAK defined error detected. |
| 1 | Current overload Current draw is above allowed operating limit. Reduce load, send a 'Clear error' command, and run the actuator in the opposite direction. |
| 2 | Hardware Internal hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 3 | Temperature Internal actuator temperature is above operating limit. Consult the documentation for correct temperature levels. The error will automatically be cleared when the temperature is within operating limits. |
| 4 | Overtoltage Input supply voltage is above operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits. |
| 5 | Undervoltage Input supply voltage is below operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits. |
| 6 | Analogue input out of range Analogue input signal is outside operating limits. Servo or Proportional. Consult the documentation for correct input signal. |
| 7 | Position not changing Internal position sensor is behaving unexpectedly and motor might stall. Please check your application for blockage or other irregularities. If the error persists, contact LINAK or replace the product. |
| 8 | Power on block state Communication has been overruled by a higher priority input. Communication is split into the following priorities: <ol style="list-style-type: none"> 1. Bus communication (CAN bus, EtherNet/IP, etc.) 2. LINAK service tool (Actuator Connect™) 3. Manual run using Red and Black wires Send a 'Clear error' command to continue. |
| 9 | Position initialisation not possible Internal initialisation parameters missing. Contact LINAK. |
| 10 | Parallel start-up Error in parallel setup. The number of connected actuators does not match your configuration. Check the configuration by using the LINAK tool Actuator Connect. |
| 11 | Parallel running The actuators are performing the internal setup and are not ready for operation. |

Parallel error codes

| Error | Description |
|-------|---|
| 12 | <p>BLDC motor</p> <p>Internal hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.</p> |
| 13 | <p>Endstop switch</p> <p>Endstop switches are behaving unexpectedly. Both endstop switches have been activated simultaneously for more than 100 ms. Perform the initialisation process by running the actuator fully extended and retracted.</p> |
| 14 | <p>Parallel communication</p> <p>Error in internal parallel communication. More than 5 communication errors in 500 ms. Please check the wire connections and re-power the complete setup.</p> |
| 15 | <p>Parallel setup stopped</p> <p>One or more actuators cannot comply with commands and stop. Master commands 'Stop' to other actuators in the network. Send 'Clear error' command to clear error. If the error persists, check your application and wire connections and re-power your complete setup.</p> |
| 24 | <p>Other error</p> <p>Actuator receives an undefined error code. This can be due to outdated firmware. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.</p> |
| 25 | <p>Position lost</p> <p>The actuator has lost track of its position. Please run the actuator completely inwards and run outwards past the area from 35-70 mm to initialise the actuator.</p> |

Contacts

FACTORIES

Denmark - Headquarters
LINAK A/S
Phone: +45 73 15 15 15
Fax: +45 74 45 80 48
Fax (Sales): +45 73 15 16 13
Web: www.linak.com

China
LINAK (Shenzhen) Actuator Systems, Ltd.
Phone: +86 755 8610 6656
Phone: +86 755 8610 6990
Web: www.linak.cn

Slovakia
LINAK Slovakia s.r.o.
Phone: +421 51 7563 444
Web: www.linak.sk

Thailand
LINAK APAC Ltd.
Phone: +66 33 265 400
Web: www.linak.com

USA
LINAK U.S. Inc.
Americas Headquarters
Phone: +1 502 253 5595
Fax: +1 502 253 5596
Web: www.linak-us.com
www.linak-latinamerica.com

SUBSIDIARIES

Australia
LINAK Australia Pty. Ltd
Phone: +61 3 8796 9777
Fax: +61 3 8796 9778
E-mail: sales@linak.com.au
Web: www.linak.com.au

Austria
LINAK Zweigniederlassung - Österreich (Wien)
Phone: +43 (1) 890 7446
Fax: +43 (1) 890 744615
E-mail: info@linak.de
Web: www.linak.at - www.linak.hu

Belgium
LINAK Actuator-Systems NV/SA
(Belgium & Luxembourg)
Phone: +32 (0)9 230 01 09
E-mail: beinfo@linak.be
Web: www.linak.be - www.fr.linak.be

Brazil
LINAK Do Brasil Comércio De Atuadores Ltda.
Phone: +55 (11) 2832 7070
Fax: +55 (11) 2832 7060
E-mail: info@linak.com.br
Web: www.linak.com.br

Canada
LINAK Canada Inc.
Phone: +1 502 253 5595
Fax: +1 416 255 7720
E-mail: info@linak.ca
Web: www.linak-us.com

Czech Republic
LINAK C&S s.r.o.
Phone: +42 058 174 1814
Fax: +42 058 170 2452
E-mail: info@linak.cz
Web: www.linak.cz - www.linak.sk

Denmark - International
LINAK International
Phone: +45 73 15 15 15
E-mail: info@linak.com
Web: www.linak.com

Denmark - Sales
LINAK Danmark A/S
Phone: +45 86 80 36 11
Fax: +45 86 82 90 51
E-mail: linak@linak-silkeborg.dk
Web: www.linak.dk

Finland
LINAK OY
Phone: +358 10 841 8700
E-mail: linak@linak.fi
Web: www.linak.fi

France
LINAK France E.U.R.L
Phone: +33 (0) 2 41 36 34 34
Fax: +33 (0) 2 41 36 35 00
E-mail: linak@linak.fr
Web: www.linak.fr

Germany
LINAK GmbH
Phone: +49 6043 9655 0
Fax: +49 6043 9655 60
E-mail: info@linak.de
Web: www.linak.de

India
LINAK A/S India Liaison Office
Phone: +91 120 4531797
Fax: +91 120 4786428
E-mail: info@linak.in
Web: www.linak.in

Ireland
LINAK UK Limited (Ireland)
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
+44 (0)796 855 1606 (UK Mobile)
+35 387 634 6554 (Rep.of Ireland Mobile)
E-mail: sales@linak.co.uk
Web: www.linak.co.uk

Italy
LINAK ITALIA S.r.l.
Phone: +39 02 48 46 33 66
Fax: +39 02 48 46 82 52
E-mail: info@linak.it
Web: www.linak.it

Japan
LINAK K.K.
Phone: 81-45-533-0802
Fax: 81-45-533-0803
E-mail: linak@linak.jp
Web: www.linak.jp

Malaysia
LINAK Actuators Sdn. Bhd.
Phone: +60 4 210 6500
Fax: +60 4 226 8901
E-mail: info@linak-asia.com
Web: www.linak.my

Netherlands
LINAK Actuator-Systems B.V.
Phone: +31 76 5 42 44 40 /
+31 76 200 11 10
E-mail: info@linak.nl
Web: www.linak.nl

New Zealand
LINAK New Zealand Ltd
Phone: +64 9580 2071
Fax: +64 9580 2072
E-mail: nzsales@linak.com.au
Web: www.linak.com.au

Norway
LINAK Norge AS
Phone: +47 32 82 90 90
E-mail: info@linak.no
Web: www.linak.no

Poland
LINAK Polska
LINAK Danmark A/S (Spółka Akcyjna)
Phone: +48 22 295 09 70 /
+48 22 295 09 71
E-mail: info@linak.pl
Web: www.linak.pl

Republic of Korea
LINAK Korea Ltd.
Phone: +82 2 6231 1515
Fax: +82 2 6231 1516
E-mail: info@linak.kr
Web: www.linak.kr

Slovakia
LINAK Slovakia S.R.O.
Phone: +421 51 7563 444
Web: www.linak.sk

Spain
LINAK Actuadores, S.L.u
Phone: +34 93 588 27 77
Fax: +34 93 588 27 85
E-mail: esma@linak.es
Web: www.linak.es

Sweden
LINAK Scandinavia AB
Phone: +46 8 732 20 00
Fax: +46 8 732 20 50
E-mail: info@linak.se
Web: www.linak.se

Switzerland
LINAK AG
Phone: +41 43 388 31 88
Fax: +41 43 388 31 87
E-mail: info@linak.ch
Web: www.linak.ch - www.fr.linak.ch
www.it.linak.ch

Taiwan
LINAK (Shenzhen) Actuator systems Ltd.
Taiwan Representative office
Phone: +886 2 272 90068
Fax: +886 2 272 90096
E-mail: sales@linak.com.tw
Web: www.linak.com.tw

Turkey
LINAK İth. İhr. San. ve Tic. A.Ş.
Phone: +90 312 4726338
Fax: +90 312 4726635
E-mail: info@linak.com.tr
Web: www.linak.com.tr

United Kingdom
LINAK UK Limited
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
E-mail: sales@linak.co.uk
Web: www.linak.co.uk

DISTRIBUTORS

Argentina
Novotec Argentina SRL
Phone: 011-4303-8989 / 8900
Fax: 011-4032-0184
E-mail: info@novotecargentina.com
Web: www.novotecargentina.com

Colombia
MEM Ltda
Phone: +[57] (1) 334-7666
Fax: +[57] (1) 282-1684
E-mail: servicioalcliente@memltda.com.co
Web: www.mem.net.co

India
Mechatronics Control Equipments India Pvt Ltd
Phone: +91-44-28558484, 85
E-mail: bala@mechatronicscontrol.com
Web: www.mechatronicscontrol.com

Indonesia
PT. Himalaya Everest Jaya
Phone: +6 221 544 8956 /+6 221 544 8965
Fax: +6 221 619 1925
Fax (Sales): +6 221 619 4658
E-mail: hejplastic-div@centrin.net.id
Web: www.hej.co.id

Israel
NetivTech LTD
Phone: +972 55-2266-535
Fax: +972 2-9900-560
E-mail: info@NetivTech.com
Web: www.netivtech.com

Singapore
Servo Dynamics Pte Ltd
Phone: +65 6844 0288
Fax: +65 6844 0070
E-mail: servodynamics@servo.com.sg

South Africa
Industrial Specialised Applications CC
Phone: +27 011 466 0346
E-mail: gartht@isagroup.co.za
Web: www.isaza.co.za

United Arab Emirates
Mechatronics
Phone: +971 4 267 4311
Fax: +971 4 267 4312
E-mail: mechtron@emirates.net.ae