

EtherNet/IP™

User Manual

EtherNet/IP®

Contents

| | |
|---|----|
| Preface | 3 |
| Terms of use | 4 |
| Revision overview..... | 5 |
| Connection diagram | 6 |
| Applicable for: LA14, LA25, LA21, LA33, LA36, LA37, LA73, LA76 and LA77 | 6 |
| Applicable for: LC3 IC..... | 7 |
| I/O specifications..... | 8 |
| Protection..... | 9 |
| Current limit..... | 9 |
| Parallel..... | 9 |
| Diagnostics | 11 |
| LED status indicator | 11 |
| Getting started | 11 |
| EtherNet/IP EDS | 11 |
| Power supply..... | 11 |
| Parameters to be verified by Actuator Connect™ | 13 |
| Command examples | 14 |
| General run prerequisites..... | 14 |
| Run the actuator outwards | 15 |
| Run the actuator to target position (150 mm)..... | 16 |
| Overcurrent state..... | 17 |
| Clear error | 17 |
| Implicit messaging | 18 |
| Assembly Data Output (Command)..... | 18 |
| Assembly Data Input (Feedback) | 19 |
| Assembly Data Input (Parallel Feedback)..... | 21 |
| Explicit messaging..... | 22 |
| Configuration..... | 22 |
| Diagnostics..... | 23 |
| Reason for last stop definition..... | 27 |
| Error codes | 28 |
| Parallel error codes..... | 30 |
| Contacts..... | 32 |

Preface

Dear User,

We are delighted that you have chosen a LINAK® product.

LINAK systems are high-tech products based on many years of experience in the manufacture and development of actuators, lifting columns, desk frames, electric control boxes, controls, batteries, accessories and chargers.

This User Manual does not address the end user. It is intended as a source of information for the equipment or system manufacturer only, and it will tell you how to install, use and maintain your LINAK electronics. The manufacturer of the end product has the responsibility to provide a User Manual, where relevant safety information from this manual is passed on to the end user.

We are convinced that your LINAK product/system will give you many years of problem-free operation.

Before our products leave the factory, they undergo both function and quality testing. Should you, nevertheless, experience problems with your product/system, you are always welcome to contact your supplier.

LINAK subsidiaries and some distributors situated all over the world have authorised service centres, which are always ready to help you. Locate your local contact information on the back page.

LINAK provides a warranty on all products. (See warranty section).

This warranty, however, is subject to correct use in accordance with the specifications, maintenance being done correctly, and any repairs being carried out at a service centre, which is authorised to repair LINAK products.

Changes in installation and use of LINAK systems can affect their operation and durability. The products may only be opened by authorised personnel.

This User Manual has been written based on the present technical knowledge. LINAK reserves the right to carry out technical modifications and keeps the associated information updated.

LINAK A/S

Terms of use

LINAK® takes great care in providing accurate and up-to-date information on its products. However, the user is responsible for determining the suitability of LINAK products for a specific application.

Due to continual development, LINAK products are subject to frequent modifications and changes. LINAK reserves the rights to conduct modifications, updates, and changes without any prior notice. For the same reason, LINAK cannot guarantee the correctness and actual status of imprinted information on its products.

LINAK uses its best efforts to fulfil orders. However, for the reasons mentioned above, LINAK cannot guarantee availability of any particular product at any given time. LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or in other written material created and produced by LINAK, LINAK subsidiaries, or LINAK affiliates.

All sales are subject to the 'Standard Terms of Sale and Delivery for LINAK A/S' available on LINAK websites.

LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.

Revision overview

Edition E

| | |
|---|-----------------------|
| Connection diagram for linear actuators updated | Page 6 |
| Connection diagram for LC3 IC updated | Page 7 |
| I/O specifications updated | Page 8 |
| Voltages removed from illustrations | Page 10 |
| 'LED status indicator' table added | Page 11 |
| 'Normal' changed to 'nominal' | Page 14 |
| 'Clear error' table added | Page 17 |
| Byte 2-5 in 'Assembly Data Output (Command)' changed to UINT8 | Page 18 |
| Status Flags b8-b15 removed | Page 19 |
| 'Assembly Data In (Feedback)' corrected to 'Assembly Data Input (Feedback)' | Page 19-20 |
| Byte 2-7 in 'Assembly Data Input (Feedback)' changed to UINT8 | Page 19-20 |
| 8-bit independent changed to Bit-independent | Page 19+21 |
| AUX Input b4-b15 changed to b4-b7 | Page 20 |
| Parallel Error Code and Parallel Status Flags changed to UINT8 | Page 21 |
| Parallel Status Flags b3-b15 changed to b3-b7 | Page 21 |
| Instance ID 20 updated in 'Diagnostics' section | Page 23 |
| 2047 corrected to 2048 | Page 27 |
| Parallel error code 25 - Position lost description updated | Page 31 |
| 'Slave' changed to 'Follower' | All over the document |

Edition D

| | |
|--|-----------------------|
| Plug type added to plug view | Page 6 |
| Item number for cable kit added | Page 6-7 |
| 'Current limit' section added | Page 9 |
| Parallel 'Check power supply' updated | Page 9 |
| EtherNet/IP EDS file information added | Page 11 |
| 'Clear error in overcurrent situation' changed to 'Overcurrent state' | Page 17 |
| 'Implicit messaging' section updated | Page 18-21 |
| 'Explicit messaging' section updated | Page 22-28 |
| 'Reason for Last Stop' table updated | Page 27 |
| Error codes updated | Page 28-29 |
| Parallel error codes updated | Page 30-31 |
| 'Soft Start' changed to 'Ramp Up' + 'Soft Stop' changed to 'Ramp Down' | All over the document |
| Identical cells in tables merged | All over the document |
| 'Read' and 'Write' changed to 'R' and 'W' | All over the document |
| LA14, LA25, LA21, LA73 and LC3 IC added | All over the document |


Edition C

| | |
|---|------------|
| LA14 and LA25 removed | Page 6 |
| LA33 added | Page 6 |
| Information about separate supplies added | Page 10 |
| Adapter settings updated | Page 13 |
| 'Command examples' section updated | Page 14-16 |
| 'Assembly data' section added | Page 17-20 |


Connection diagram

Applicable for: LA14, LA25, LA21, LA33, LA36, LA37, LA73, LA76 and LA77


| | |
|--------------|------------|
| BROWN | 24/48 V DC |
| BLUE | GND |



| | |
|----------|-------------------------|
| 4 | Split power supply V DC |
| 1 | Extends the actuator |
| 2 | Retracts the actuator |
| 3 | Parallel data + |
| 5 | Parallel data - |



| | |
|----------|---------|
| 1 | ETH_TX+ |
| 2 | ETH_RX+ |
| 3 | ETH_TX- |
| 4 | ETH_RX- |



Connection diagram

Applicable for: LC3 IC

BROWN 24/48 V DC

BLUE GND



ORANGE Split power supply V DC

RED Extends the actuator

BLACK Retracts the actuator

VIOLET Parallel data +


WHITE Parallel data -

YELLOW Not to be connected

GREEN Not to be connected

LIGHT BLUE Not to be connected

GREY Not to be connected




Molex mini-fit
12-pin

1 ETH_TX+

3 ETH_RX+


2 ETH_TX-

6 ETH_RX-



RJ45

I/O specifications

| Input/Output | | Specification | Comments |
|----------------|-----------------------|---|--|
| Description | | The physical layer conforms to the IEEE 802.3-2018 standard with communication speeds of 10 Mbps and 100 Mbps, respectively. Cable length is reduced to = 100 m without repeater, as determined by IEEE 802.3-2018. |  |
| Brown | | Connect Brown to positive 24/48 V DC | <p>Note:</p> <p>Do not change the power supply polarity on the Brown and Blue wires!</p> <p>Only for powering the motor driver module.</p> <p>Power supply GND is electrically connected to the housing through a capacitor and resistor in parallel.</p> |
| Blue | | Connect Blue to negative GND | |
| PIN out | | Data cable M12 - 5-pin male OR Molex mini-fit - 12-pin | |
| M12 | Molex mini-fit | | |
| Pin 4 | Orange | Split power supply V DC | <p>Split power supply:</p> <p>24 V DC with ≈ 28 mA current consumption. 48 V DC with ≈ 16 mA current consumption.</p> <p>The split power supply uses the common GND from the power supply (Blue).</p> <p>Split power supply is only for powering the communication of the integrated controller.</p> |
| Pin 1 | Red | Extends the actuator | <p>The signal becomes active at:</p> <p>$V_{IN} > 67\%$ of V DC</p> <p>The signal becomes inactive at:</p> <p>$V_{IN} < 33\%$ of V DC</p> <p>Input current: 10 mA</p> |
| Pin 2 | Black | Retracts the actuator | |
| Pin 3 | Violet | Parallel data + | <p>The Parallel drive function will support up to 8 actuators running simultaneously.</p> <p>It is possible to run Parallel with a main power supply or separate power supplies.</p> |
| Pin 5 | White | Parallel data - | |
| PIN out | | Data cable M12 - 4-pin female OR RJ45 | |
| M12 | RJ45 | | |
| Pin 1 | Pin 1 | ETH_TX+ | |
| Pin 2 | Pin 3 | ETH_RX+ | |
| Pin 3 | Pin 2 | ETH_TX- | |
| Pin 4 | Pin 6 | ETH_RX- | |

Protection

Current limit

Current limits can be configured to avoid crushing when meeting an obstacle. These values can be adjusted according to your preferences. Use default values or finetune your current limits with 0.25 A/bit.

It is important to note that current limits should not be relied upon as a general stop function, as this will potentially stress the mechanics and could lead to long-term damage to the actuator.

Furthermore, current limits do not correlate directly with the actuator's load curves, meaning they should not be used as indicators of load. Various tolerances in components such as the spindle, nut, and gears can also affect the current consumption of the actuator. Operation in environments with temperatures below 0°C will also increase the current consumption. When temperature drops below 0°C, the default current limit will change to a higher value.

Actuator specific current limit values (above and below reference temp.) can be found in the respective actuator user manual or in the Actuator Connect™ service tool under 'Protection'.

Parallel


The industrial LINAK® actuators can be ordered with parallel functionality. If this feature is enabled, it is possible to run up to 8 actuators in a parallel system with just one actuator occupying an Ethernet port connection. The system works as a critical parallel, meaning that all actuators must be present in the system and have the exact same configuration (both mechanical and software functionality).

Below is a checklist to ensure that the system operates as intended:

| Action | Description |
|-------------------------------------|---|
| Set up parallel in Actuator Connect | Each actuator must be configured to operate in parallel (2-8 actuators). This can be set up using the Actuator Connect tool. <i>Please note: In some cases this is pre-configured from factory.</i> |
| Wire up the system | The actuators feature internal communication for parallel synchronisation and error codes. |
| Check cable lengths | Keep the total length of the communication line below 40 meters to avoid communication dropouts. In a parallel system with 8 actuators this would result in signal cable lengths of <5 metres. |
| Check power supply | It is also possible to use two or more separate power supplies in parallel under the condition that they have the same voltage and wattage output. It is essential that all power supplies share a common ground connection (Blue wire). Please respect actuator specifications regarding voltage level and current consumption! |

Parallel


Option 1 - A simple parallel setup



In a simple parallel setup there is only one actuator connected to the network. This actuator receives run commands and shares data with the controller. The remaining actuators in the system are only connected to internal parallel communication. This way, the internal communication ensures that the system operates in parallel and stops in case of an obstacle, or when other errors occur on one of the actuators.

The actuators share simple error messages with the master, which can be distributed via the network.

Option 2 - Bus communication on all actuators






If there is a need for e.g. monitoring the real-time data of each actuator, it is possible to connect all actuators as nodes to the network. This will provide comprehensive usage data, which can be used to enhance performance in the application. Similar to option 1, this requires that all actuators are connected to internal parallel communication.

It is also possible to use two separate power supplies in parallel under the condition that they have the same voltage and wattage output. It is essential that both power supplies share a common ground connection (Blue wire).

Diagnostics

LED status indicator

Some 9-pin and 12-pin actuators (not 6-pin) are equipped with an LED status indicator. The LED can show different colours, depending on the state of the actuator:

| LED | Status |
|---|-------------------------------|
|  | OK |
|  | Inoperative (external errors) |
|  | Inoperative (internal errors) |

Getting started

This section further describes how to communicate with LINAK® EtherNet/IP™ actuators and contains examples of typical user scenarios and application solutions. All examples include references to registers which are further described in detail below.

EtherNet/IP EDS

An Electronic Data Sheet (EDS) describes the configuration and capabilities of an EtherNet/IP device, enabling industrial automation software to correctly identify, configure, and communicate with it. These files include essential details such as device identity, input/output (I/O) data, and key parameters, making it easier to integrate the device into a network.

The LINAK_EtherNetIP_EDS file is available for download by using the following link: [LINAK_EtherNetIP_EDS.zip](#)

Power supply

EtherNet/IP actuators are available with the following supply voltage range: 24 and 48 V DC. The accepted supply voltage range is specified for the version as shown below:

| Supply voltage | Function | Voltage range | | |
|----------------|---------------------------|-----------------|------------------|------------------|
| | | V _{IN} | V _{TYP} | V _{MAX} |
| 24 V | Motor | 18 V | 24 V | 32 V |
| | EtherNet/IP communication | 10 V | 24 V | 39 V |
| 48 V | Motor | 36 V | 48 V | 58 V |
| | EtherNet/IP communication | 10 V | 48 V | 60 V |



For more information about wiring/connector, please see the connection diagram.


Configuration

Before being integrated into an EtherNet/IP system, a few of the actuator parameters must be checked and eventually changed. This preparation is done via the use of the configuration tool Actuator Connect™ and guarantees that the actuator is able to execute basic functionality.

Further fine-tuning may be required to fulfil system or application requirements. Via this tool it is also possible to access historical usage data and real-time monitoring.


Valid for LA14 and LA25:

A separate configuration cable kit (item no. 0257901 = straight Y-cable + USB2LIN) is required to use Actuator Connect on a PC. This cable must be connected to the 9-pin connector on the actuator side. On the opposite side, power must be applied to the flying leads, and the USB connector must be inserted into your PC.



Valid for LA21, LA33, LA36, LA37, LA73, LA76, LA77, and LC3 IC:

A separate configuration cable (item no. 0367996) is required to use Actuator Connect on a PC. This cable must be connected to the 6-pin and 9-pin connector on the actuator side. On the opposite side, power must be applied to the flying leads, and the USB connector must be inserted into your PC.



For more information about wiring/connector, please see the connection diagram.

Parameters to be verified by Actuator Connect™

| Parameters | Description |
|-------------|---|
| DHCP | DHCP is a client/server protocol that automatically provides an IP address. If enabled: below parameters are not configurable |
| IP Address | Set the device IP address to a unique address in the network. 192.168.1.10 (Default) |
| Subnet mask | Set the subnet mask. 255.255.255.0 (default) |
| Gateway | Set the gateway. 192.168.1.1 (default) |



Users are strongly advised against configuring their assets directly to the public internet. By taking this precautionary measure, the risk of unauthorized and malicious cyber activities from external threats is significantly reduced.

Command examples

Before the actuator can engage movement, some general prerequisites must be fulfilled. Timing (e.g. when the actuator is still moving), environmental conditions and errors may indicate that the actuator is in a state where further operation is not possible.

General run prerequisites

| Step | Read/Write | Assembly Instance ID* | Action |
|------|------------|---|---|
| 1 | W | Command details AID 150 [0x96] Byte 0-1 | "Position" must be set to = 64259 [0xFB03] for 'Stop'. To prevent unintended movement it is required to send a 'Stop' command before running the actuator. |
| 2 | R | Feedback status details AID 100 [0x64] Byte 4 | "Error Code" must be = 0 [0x00]. |
| 3 | | Feedback status details AID 100 [0x64] Byte 3 | "Status Flags" bit 2 (Overcurrent) must be = 0. |
| 4 | | Feedback status details AID 100 [0x64] Byte 3 | "Status Flags" bit 5 (Heartbeat needed) must be = 0. |
| 5 | | Feedback status details AID 100 [0x64] Byte 3 | "Status Flags" bit 6 (Actuator is running outside nominal conditions) must be = 0. |

* AID 100 = Feedback / AID 150 = Command

Run the actuator outwards

| Step | Read/Write | Assembly Instance ID* | Action |
|------|------------|---|---|
| 1 | | - | Check that general run prerequisites are fulfilled. |
| 2 | W | Command details AID 150 [0x96] Byte 2 | “Current” must be set to a value. 0-250 [0x00-FA] = Current limit 0.25 A/bit 251 [0xFB] = Default current limit set via Actuator Connect™ 252-255 [0xFC-FF] = Reserved |
| 3 | | Command details AID 150 [0x96] Byte 3 | “Speed” must be set to a value. 0-200 [0x00-FA] = Speed 0.5% /bit 201-250 [0xC9-FA] = 100% speed 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 4 | | Command details AID 150 [0x96] Byte 4 | “Ramp Up” must be set to a value. 0-250 [0x00-FA] = Start ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 5 | | Command details AID 150 [0x96] Byte 5 | “Ramp Down” must be set to a value. 0-250 [0x00-FA] = Stop ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved |
| 6 | | Command details AID 150 [0x96] Byte 0-1 | “Position” must be set to = 64257 [0xFB01] for ‘Run out’. |
| 7** | R | Feedback status details AID 100 [0x64] Byte 3 | “Status Flags” bit 3 and bit 1 change to 1 to indicate that: Bit 3 = Actuator is running out Bit 1 = Endstop reached signal out |

* AID 100 = Feedback / AID 150 = Command

** Optional

Run the actuator to target position (150 mm)

| Step | Read/Write | Assembly Instance ID* | Action |
|------|------------|---|---|
| 1 | | - | Check that general run prerequisites are fulfilled. |
| 2 | W | Command details AID 150 [0x96] Byte 2 | <p>“Current” must be set to a value.</p> <p>0-250 [0x00-FA] = Current limit 0.25 A/bit 251 [0xFB] = Default current limit set via Actuator Connect™ 252-255 [0xFC-FF] = Reserved</p> |
| 3 | | Command details AID 150 [0x96] Byte 3 | <p>“Speed” must be set to a value.</p> <p>0-200 [0x00-FA] = Speed 0.5% /bit 201-250 [0xC9-FA] = 100% speed 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved</p> |
| 4 | | Command details AID 150 [0x96] Byte 4 | <p>“Ramp Up” must be set to a value.</p> <p>0-250 [0x00-FA] = Start ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved</p> |
| 5 | | Command details AID 150 [0x96] Byte 5 | <p>“Ramp Down” must be set to a value.</p> <p>0-250 [0x00-FA] = Stop ramp time 0.05 s/bit 251 [0xFB] = Default speed set via Actuator Connect 252-255 [0xFC-FF] = Reserved</p> |
| 6 | | Command details AID 150 [0x96] Byte 0-1 | <p>“Position” must be set to = 1500 [0x05DC] for ‘Run to Target Position 150 mm’.</p> |
| 7** | R | Feedback status details AID 100 [0x64] Byte 3 | <p>“Status Flags” bit 3 or bit 4 change to 1 to indicate that:</p> <p>Bit 3 = Actuator is running out Bit 4 = Actuator is running in</p> |

Overcurrent state

If an overcurrent occurs, the actuator will be stopped and blocked in that direction until an activation in the opposite direction has been made or the system has been re-powered.

| Step | Read/Write | Assembly Instance ID* | Action |
|------|------------|---|--|
| 1 | R | Feedback status details AID 100 [0x64] Byte 3 | Confirm that "Status Flags" bit 2 is = 1 for 'Overcurrent' |
| 2 | W | Command details AID 150 [0x96] Byte 0-1 | "Position" must be set to run in the opposite direction of the blockage Set to = 64257 [0xFB01] for 'Run out' or Set to = 64258 [0xFB02] for 'Run in' |
| 3 | R | Feedback status details AID 100 [0x64] Byte 3 | "Status Flags" bits change to 1 to indicate that either: Bit 3 = Actuator is running out Bit 4 = Actuator is running in Bit 1 = Endstop reached out Bit 0 = Endstop reached in |

* AID 100 = Feedback / AID 150 = Command

** Optional

Clear error

If an error occurs, the actuator will be stopped, and normal movement will not be possible.

| Step | Read/Write | Assembly Data* | Action |
|------|------------|-----------------|---|
| 1 | R | ADI Byte 4 | Confirm that "Error Code" is not = 0 |
| 2 | W | ADO Byte 0-1 | "Position" set to = 64256 (Clear Error Codes) |
| 3 | R | ADI Byte 4 | Confirm that "Error Code" is = 0 If "Error Code" is not = 0, then correct the error in the system and repeat step 2. |

* ADI = Assembly Data In / ADO = Assembly Data Out

Implicit messaging

EtherNet/IP process data refers to real-time, cyclic data exchanged between industrial control devices for automation tasks, and configuration data for setting up and managing these devices.

This data is organised using the Common Industrial Protocol (CIP) and transported within TCP/IP packets, enabling communication for both time-critical operations (implicit messaging) and diagnostics or parameter uploads (explicit messaging).

Assembly Data Output (Command)

| Command Assembly Instance ID 150 Class 1 Implicit I/O messaging | | | | | |
|---|---------|--------|---------------|----------|-----------------|
| Byte 5 [MSB] | Byte 4 | Byte 3 | Byte 2 | Byte 1 | Byte 0 [LSB] |
| Ramp Down | Ramp Up | Speed | Current Limit | Position | |

| Assembly Instance ID 150 | | | | | |
|--------------------------|---------------|-----------|-------------|--|------------|
| Byte(s) | Command | Data type | Details | Description | Scaling |
| Byte 0-1 | Position | UINT16 | 0-64255 | Run to position | 0.1 mm/bit |
| | | | 64256 | Clear Error Code (See Assembly Data in Byte 4) | |
| | | | 64257 | Run out | |
| | | | 64258 | Run in | |
| | | | 64259 | Stop | |
| | | | 64260 | Recovery run out | |
| | | | 64261 | Recovery run in | |
| | | | 64262-65535 | Invalid value Actuator will not run | |
| Byte 2 | Current Limit | UINT8 | 0-250 | Maximum current limit | 0.25 A/bit |
| | | | 251 | Default current limit | |
| | | | 252-255 | Invalid value Actuator will not run | |
| Byte 3 | Speed | UINT8 | 0-200 | Speed | 0.5%/bit |
| | | | 201-250 | 100% speed | |
| | | | 251 | Default speed | |
| | | | 252-255 | Invalid value Actuator will not run | |
| Byte 4 | Ramp Up | UINT8 | 0-250 | Ramp up time | 0.05 s/bit |
| | | | 251 | Default ramp up time | |
| | | | 252-255 | Invalid value Actuator will not run | |
| Byte 5 | Ramp Down | UINT8 | 0-250 | Ramp down time | 0.05 s/bit |
| | | | 251 | Default ramp down time | |
| | | | 252-255 | Invalid value Actuator will not run | |

Assembly Data Input (Feedback)

| Feedback Assembly Instance ID 100 Class 1 Implicit I/O messaging | | | | | | | |
|--|--------|--------|------------|--------------|--------------|----------|-----------------|
| Byte 7 [MSB] | Byte 6 | Byte 5 | Byte 4 | Byte 3 | Byte 2 | Byte 1 | Byte 0 [LSB] |
| AUX Inputs | Speed | | Error Code | Status Flags | Current Draw | Position | |

| Assembly Instance ID 100 | | | | | |
|--------------------------|--------------|-----------|-------------|--|--|
| Byte(s) | Status | Data type | Details | Description | Scaling |
| Byte 0-1 | Position | UINT16 | 0-64255 | Position of the actuator | 0.1 mm/bit |
| | | | 64256-65023 | Reserved | |
| | | | 65024 | Position lost | |
| | | | 65025-65535 | Reserved | |
| Byte 2 | Current Draw | UINT8 | 0 | Not running | 0.25 A/bit |
| | | | 1-250 | Motor current draw | |
| | | | 251-253 | Reserved | |
| | | | 254 | Fault in current measurement circuit | |
| | | | 255 | Reserved | |
| Byte 3 | Status Flags | UINT8 | b0 | Endstop reached in | Bit-independent status indicators |
| | | | b1 | Endstop reached out | |
| | | | b2 | Overcurrent | |
| | | | b3 | Running out | |
| | | | b4 | Running in | |
| | | | b5 | Communication heartbeat needed | |
| | | | b6 | Actuator is running outside nominal conditions | |
| | | | b7 | Reserved. Always high | |
| Byte 4 | Error Code* | UINT8 | 0 | No error detected | 8-bit error code showing the currently active error with the highest priority only |
| | | | 1 | Power on block state | |
| | | | 2 | Position sensor | |
| | | | 3 | Overvoltage | |
| | | | 4 | Undervoltage | |
| | | | 5 | Communication sync. | |
| | | | 6 | Endstop switch | |
| | | | 7 | Temperature | |
| | | | 8 | Motor controller | |
| | | | 9 | Internal power supply | |
| | | | 10 | Internal current measurement | |

* See Error Code descriptions in section: [Error codes](#)

Assembly Data Input (Feedback)

| Assembly Instance ID 100 | | | | | |
|--------------------------|-------------|-----------|------------|--------------------------------------|--|
| Byte(s) | Status | Data type | Details | Description | Scaling |
| Byte 4 | Error Code* | UINT8 | 11 | Parallel arbitration | 8-bit error code showing the currently active error with the highest priority only |
| | | | 12 | Position not changing | |
| | | | 13 | Position initialisation not possible | |
| | | | 14 | Alone in parallel system | |
| | | | 15 | Incorrect number in parallel system | |
| | | | 16 | Hardware | |
| | | | 17 | BLDC motor | |
| | | | 18 | Parallel communication | |
| | | | 19 | Parallel running | |
| | | | 20 | Parallel setup stopped | |
| | | | 254 | Other internal error (Not specified) | |
| | | | 255 | Other external error (Not specified) | |
| Byte 5-6 | Speed | UINT16 | 0-4015 | Speed of actuator | 0.1 mm/s / bit |
| | | | 4016-65535 | Reserved | |
| Byte 7 | AUX Inputs | UINT8 | b0-b1 | Input 1 level | 1 bit/ 25% VCC |
| | | | b2-b3 | Input 2 level | |
| | | | b4-b7 | Reserved | |

* See Error Code descriptions in section: [Error codes](#)

Assembly Data Input (Parallel Feedback)

| Parallel Feedback Assembly Instance ID 100 Class 1 Implicit I/O messaging | | | | | |
|---|---------------------|-----------------------|---------|--------|--------|
| Byte 13 [MSB] | Byte 12 | Byte 11 | Byte 10 | Byte 9 | Byte 8 |
| Parallel Status Flags | Parallel Error Code | Parallel Error Source | | | |

| Assembly Instance ID 100 | | | | | |
|--------------------------|-----------------------|-----------|-----------------|--|---|
| Byte(s) | Command | Data type | Details | Description | Unit |
| Byte 8-11 | Parallel Error Source | UINT32 | 0 | No error detected | Decimal to IPv4 |
| | | | 1-4.294.967.295 | IP address of the actuator with highest priority error | |
| Byte 12 | Parallel Error Code* | UINT8 | 0 | No error detected | 8-bit error code indicating the currently active error of highest priority on any actuator in the parallel system |
| | | | 1 | Current overload | |
| | | | 2 | Hardware | |
| | | | 3 | Temperature | |
| | | | 4 | Overvoltage | |
| | | | 5 | Undervoltage | |
| | | | 6 | Analogue input out of range | |
| | | | 7 | Position not changing | |
| | | | 8 | Power on block state | |
| | | | 9 | Position initialisation not possible | |
| | | | 10 | Parallel start-up | |
| | | | 11 | Parallel running | |
| | | | 12 | BLDC motor | |
| | | | 13 | Endstop switch | |
| | | | 14 | Parallel communication | |
| | | | 15 | Parallel setup stopped | |
| 24 | Other error | | | | |
| 25 | Position lost | | | | |
| Byte 13 | Parallel Status Flags | UINT8 | b0 | Parallel endstop reached out | Bit-independent status indicators |
| | | | b1 | Parallel endstop reached in | |
| | | | b2 | Parallel running outside nominal conditions | |
| | | | b3-b7 | Reserved. Always high | |

* See Parallel Error Code descriptions in section: [Parallel error codes](#)

Explicit messaging

EtherNet/IP explicit messaging is a client-server communication method using TCP/IP that allows an originator (client) to request specific data or services from a target device (server) for non-time-critical operations like configuration, diagnostics, or register reads/writes.

Each request contains explicit instructions for the target device to decode and respond to, making it less efficient but highly flexible for accessing individual data points on demand

These parameters are addressed by a combination of Class, Instance, and Attribute.

To read a parameter Read Attribute Single (0x0E) must be used. To write a parameter Write Attribute Single (0x10) must be used. For Class ID, Parameter object (0x0F) must be used. Attribute ID is 1 for all instance IDs in this section.

Configuration

| Configuration Assembly Instance ID 151 Class 3 Explicit Messaging | | | | | | |
|---|----------------------------|-----------|-----------|--|--------------------------|--------|
| Instance ID | Parameter | Data type | Details | Description | Scaling | Access |
| 1 | Current Limit - Outwards | UINT8 | 0-255 | No error detected | 0.25 A/bit | R/W |
| | | | | IP address of the actuator with highest priority error | | |
| 2 | Current Limit - Inwards | | | No error detected | | |
| 3 | Ramp Up - Outwards | UINT16 | 0-65535 | Works only when AID 150 "Ramp Up" is 251 | 1 ms/bit | R/W |
| 4 | Ramp Up - Inwards | | | | | |
| 5 | Ramp Down - Outwards | | | Works only when AID 150 "Ramp Down" is 251 | | |
| 6 | Ramp Down - Inwards | | | | | |
| 7 | Maximum Speed | UINT8 | 0-200 | Overrules AID 150 "Speed" | 0.5% /bit | R/W |
| | | | 201-255 | | 100% | |
| 8 | Virtual Endstop - Outwards | UINT16 | 0 | Sets the Virtual Endstop Outwards position | Disabled | R/W |
| | | | 1-699 | | Do NOT set below 70 mm** | |
| | | | 700-65535 | | 0.1 mm/bit | |
| 9 | Virtual Endstop - Inwards | UINT16 | 0 | Sets the Virtual Endstop Inwards position | Disabled | R/W |
| | | | 1-350 | | 0.1 mm/bit | |
| | | | 351-65535 | | Do NOT set above 35 mm** | |

* Actuator must power cycle before changes apply.

** Virtual limits set in the Initialisation zone will make Initialisation impossible.

Diagnostics

| Diagnostics Assembly Instance ID 151 Class 3 Explicit Messaging | | | | | | |
|---|---------------------------------------|-----------|---------|--------------------------------------|---------|--------|
| Instance ID | Parameter | Data type | Details | Description | Scaling | Access |
| 10 | UIN | UINT32 | | Unique 8-digit identification number | | R |
| 11 | Variant | UINT32 | | SWxxxxxxxVx-x | | R |
| 12 | Version Major | | | SWxxxxxxxVx-x | | |
| 13 | Version Minor | | | SWxxxxxxxVx-x | | |
| 14 | Config Production Order Number | UINT32 | | Unique 8-digit identification number | | R |
| 15 | Production Date | | | yyyymmdd | | |
| 16 | Max. Current Seen | UINT8 | | 0.25 A/bit | | |
| 17 | Max. FET Temperature Seen | | | 1°C /bit - 40°C | | |
| 18 | Max. Ambient Temperature Seen | | | | | |
| 19 | Min. Ambient Temperature Seen | | | | | |
| 20 | Total Current Usage | UINT32 | | 1 (Ampere*seconds)/bit | | |
| 21 | Total Runtime | | | 1 s/bit | | |
| Number of stops due to | | | | | | |
| 22 | Oversvoltage | UINT8 | | Number of stops | | R |
| 23 | FET Over-temperature | | | | | |
| 24 | Ambient Over-Temperature | | | | | |
| 25 | Undervoltage | | | | | |
| 26 | Hall Error | | | | | |
| 27 | Endstop Switch Error | | | | | |
| 28 | Default Current Limit Overloads - Out | | | | | |
| 29 | Default Current Limit Overloads - In | | | | | |

Diagnostics

| Diagnostics Assembly Instance ID 151 Class 3 Explicit Messaging | | | | | | |
|---|--------------------------------------|-----------|---------|--|---------|--------|
| Instance ID | Parameter | Data type | Details | Description | Scaling | Access |
| Number of resettable stops due to | | | | | | |
| 30 | Custom Current Limit Overloads - Out | UINT8 | | Can be used to keep track of current overload stops from the last reset. Can only be set to 0. | | R/W |
| 31 | Custom Current Limit Overloads - In | | | | | |
| Number of | | | | | | |
| 32 | Communication Errors | UINT16 | | Number of | | R |
| 33 | Endstop Reached - Out | UINT32 | | | | |
| 34 | Endstop Reached - In | | | | | |
| 35 | Starts - Out | | | | | |
| 36 | Starts - In | | | | | |
| 37 | Total Piston Distance Traveled | UINT32 | | 5 m/bit | | R |
| Reason for Last Stop – ID 0: See Reason for Last Stop definitions in section below | | | | | | |
| 38 | Reason | UINT16 | | Reason for stop | | R |
| 39 | Count | UINT8 | | Number of stops in a row | | |
| 40 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |
| Reason for Last Stop – ID 1: See Reason for Last Stop definitions in section below | | | | | | |
| 41 | Reason | UINT16 | | Reason for stop | | R |
| 42 | Count | UINT8 | | Number of stops in a row | | |
| 43 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |
| Reason for Last Stop – ID 2: See Reason for Last Stop definitions in section below | | | | | | |
| 44 | Reason | UINT16 | | Reason for stop | | R |
| 45 | Count | UINT8 | | Number of stops in a row | | |
| 46 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |

Diagnostics

| Diagnostics Assembly Instance ID 151 Class 3 Explicit Messaging | | | | | | |
|---|--------------------------------|-----------|---------|--|---------|--------|
| Instance ID | Parameter | Data type | Details | Description | Scaling | Access |
| Reason for Last Stop – ID 3: See Reason for Last Stop definitions in section below | | | | | | |
| 47 | Reason | UINT16 | | Reason for stop | 1 s/bit | R |
| 48 | Count | UINT8 | | Number of stops in a row | | |
| 49 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |
| Reason for Last Stop – ID 4: See Reason for Last Stop definitions in section below | | | | | | |
| 50 | Reason | UINT16 | | Reason for stop | 1 s/bit | R |
| 51 | Count | UINT8 | | Number of stops in a row | | |
| 52 | Powered Time | UINT32 | | Powered time when the last stop occurred | | |
| 53 | Total Corrected Distance | UINT32 | | 1 mm/bit | | R |
| 54 | FET Temperature | UINT8 | | 1°C /bit - 40°C | | |
| 55 | Ambient Temperature | | | | | |
| 56 | Number of Hall Shifts at Learn | UINT16 | | 0.1 mm/bit | | R |
| 57 | Zero Point Offset at Learn | | | | | |
| 58 | Production Order Number | UINT32 | | Unique 8-digit identification number | | |
| LINAK Special Functions | | | | | | |
| 59 | Functions | UINT8 | 0 | Reserved | | R |
| | | | 1 | Restart actuator | | |
| | | | 2-255 | Reserved | | |
| IP Address in Parallel System | | | | | | |
| 60 | Address 1 | UINT32 | | Sorted in descending order | | R |
| 61 | Address 2 | | | | | |
| 62 | Address 3 | | | | | |
| 63 | Address 4 | | | | | |
| 64 | Address 5 | | | | | |
| 65 | Address 6 | | | | | |
| 66 | Address 7 | | | | | |
| 67 | Address 8 | | | | | |

Diagnostics

| Diagnostics Assembly Instance ID 151 Class 3 Explicit Messaging | | | | | | |
|---|----------------|-----------|---------|--------------------------------|---------|--------|
| Instance ID | Parameter | Data type | Details | Description | Scaling | Access |
| 68 | Powered Time | UINT32 | | 1 s/bit | | R |
| 69 | Remaining Life | UINT8 | 0-100 | Remaining life (Counting down) | 1% /bit | |
| | | | 101-249 | Reserved | | |
| | | | 250 | Remaining life not supported | | |
| | | | 251-255 | Reserved | | |

Reason for last stop definition

| Reason for Last Stop | Function | Description |
|----------------------|--|--|
| 1 | H-bridge fault | There is a hardware problem causing the system to malfunction or the gate driver to not respond correctly. |
| 2 | Overtemperature | The device or the surrounding temperature got too hot while it was running. |
| 4 | Undervoltage | The voltage dropped below the required level while it was running. |
| 8 | Overcurrent | Current consumption exceeded the limit, resulting in a time-out or an actuator stall. |
| 16 | SMPS fault | The 12 V and/or 5 V levels are not within the normal range. |
| 32 | Endstop fault | Both EOS switches were turned on at the same time while running. |
| 64 | Hall fault | One Hall sensor changed more than 10 times while the motor voltage was high, but the other sensor did not change. |
| 256 | Overvoltage | The voltage went too high while it was running, probably because of the braking. |
| 512 | Position not changing | Even though power is above the level needed for the motor to turn, the position doesn't change. |
| 1024 | Hardware fault | A hardware problem has occurred. Possible reasons might include issues with the gate driver, incorrect current measurements, or a malfunctioning motor sensor. |
| 2048 | Communication drop-out | The source of the request stopped, or the signal was lost. |
| 4096 | Change of interface | The actuator is connected to a more important system than the one that made the request. |
| 4097 | Parallel master detected a change in the number of connected followers | The parallel system stopped because a registered device disconnected, or a new device connected. |
| 4098 | Parallel master was stopped by a follower | A parallel master stopped running because a follower requested the master to hard stop. |
| 4099 | Parallel follower lost connection to master | A parallel follower stopped running because the connection to the master was lost. |
| 4100 | Parallel communication fault | An actuator in the parallel system stopped working because it had too many communication errors in a short time. |

Error codes

All error codes apply to the entire TECHLINE® interface portfolio; some may not relate to your specific interface or product type.

| Error | Description |
|-------|---|
| 0 | No error detected No LINAk defined error detected. |
| 1 | Power on block state As a safety precaution to prevent unintentional movement at power-up, the actuator will not run until a 'Stop' command or 'Clear error' command has been sent. |
| 2 | Position sensor Position sensors are outside of expected operating range. Example: 10 pulses were reported on one Hall sensor and no Hall pulses on the other. Send 'Clear error' command to clear error. If the error persists, contact LINAk or replace the product. |
| 3 | Overvoltage Input supply voltage is above operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits. |
| 4 | Undervoltage Input supply voltage is below operating voltage level. The error can only be cleared by sending a 'Clear error' command once the voltage is within the acceptable range. Consult the documentation for correct voltage levels. |
| 5 | Communication sync. Heartbeat from the master is not within the expected heartbeat interval. Consult the documentation for minimum requirements for heartbeat interval. |
| 6 | Endstop switch Endstop switches are behaving unexpectedly. Example: Both endstop switches have been activated simultaneously for more than 100 ms. Perform the initialisation process by running the actuator fully extended and retracted. |
| 7 | Temperature Internal actuator temperature is above operating limit. Consult the documentation for correct temperature levels. The error will automatically be cleared when the temperature is within operating limits. |
| 8 | Internal motor controller Internal motor controller hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAk or replace the product. |
| 9 | Internal power supply The internal power supply is behaving unexpectedly. Send 'Clear error' command to clear error. If the error persists, contact LINAk or replace the product. |
| 10 | Internal current measurement Internal current reference is outside the expected limits. Send 'Clear error' command to clear error. If the error persists, contact LINAk or replace the product. |
| 11 | Parallel arbitration Start-up parallel configuration procedure in progress. |
| 12 | Position not changing Internal position sensor is behaving unexpectedly and motor might stall. Please check your application for blockage or other irregularities. If the error persists, contact LINAk or replace the product. |
| 13 | Position initialisation not possible Internal initialisation parameters missing. Contact LINAk. |

Error codes

| Error | Description |
|-------|--|
| 14 | Alone in parallel system Incorrect number of actuators in parallel system. |
| 15 | Incorrect number in parallel system Incorrect number of actuators in parallel system or wrongly configured. |
| 16 | Hardware There is an internal motor controller malfunction affecting the actuator's ability to operate correctly. Contact LINAK. |
| 17 | BLDC motor Position sensors are outside of expected operating range. Example: 10 pulses were reported on one Hall sensor and no Hall pulses on the other. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 18 | Parallel communication There are issues with the communication setup among the master and the follower devices. Make sure all cables are secured properly in the connectors. |
| 19 | Parallel running Parallel out of sync. |
| 20 | Parallel setup stopped The parallel master was stopped by a follower with some fault. To diagnose the specific issue, refer to the separate parallel feedback where the error codes from the followers can be read for more detailed information. |
| 254 | Other internal error (Not specified) Unspecified internal hardware/software error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 255 | Other external error (Not specified) Unspecified external hardware/software error. Please inspect your application for possible issues. Send 'Clear error' command to clear error. |

Parallel error codes

All error codes apply to the entire TECHLINE® interface portfolio; some may not relate to your specific interface or product type.

| Error | Description |
|-------|--|
| 0 | No error detected No LINAK defined error detected. |
| 1 | Current overload Current draw is above allowed operating limit. Reduce load, send a 'Clear error' command, and run the actuator in the opposite direction. |
| 2 | Hardware Internal hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product. |
| 3 | Temperature Internal actuator temperature is above operating limit. Consult the documentation for correct temperature levels. The error will automatically be cleared when the temperature is within operating limits. |
| 4 | Overvoltage Input supply voltage is above operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits. |
| 5 | Undervoltage Input supply voltage is below operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits. |
| 6 | Analogue input out of range Analogue input signal is outside operating limits. Servo or Proportional. Consult the documentation for correct input signal. |
| 7 | Position not changing Internal position sensor is behaving unexpectedly and motor might stall. Please check your application for blockage or other irregularities. If the error persists, contact LINAK or replace the product. |
| 8 | Power on block state Communication has been overruled by a higher priority input. Communication is split into the following priorities: <ol style="list-style-type: none"> 1. Bus communication (CAN bus, EtherNet/IP, etc.) 2. LINAK service tool (Actuator Connect™) 3. Manual run using Red and Black wires Send a 'Clear error' command to continue. |
| 9 | Position initialisation not possible Internal initialisation parameters missing. Contact LINAK. |
| 10 | Parallel start-up Error in parallel setup. The number of connected actuators does not match your configuration. Check the configuration by using the LINAK tool Actuator Connect. |
| 11 | Parallel running The actuators are performing the internal setup and are not ready for operation. |

Parallel error codes

| Error | Description |
|-------|---|
| 12 | <p>BLDC motor</p> <p>Internal hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.</p> |
| 13 | <p>Endstop switch</p> <p>Endstop switches are behaving unexpectedly. Both endstop switches have been activated simultaneously for more than 100 ms. Perform the initialisation process by running the actuator fully extended and retracted.</p> |
| 14 | <p>Parallel communication</p> <p>Error in internal parallel communication. More than 5 communication errors in 500 ms. Please check the wire connections and re-power the complete setup.</p> |
| 15 | <p>Parallel setup stopped</p> <p>One or more actuators cannot comply with commands and stop. Master commands 'Stop' to other actuators in the network. Send 'Clear error' command to clear error. If the error persists, check your application and wire connections and re-power your complete setup.</p> |
| 24 | <p>Other error</p> <p>Actuator receives an undefined error code. This can be due to outdated firmware. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.</p> |
| 25 | <p>Position lost</p> <p>The actuator has lost track of its position. Please run the actuator completely inwards and run outwards past the area from 35-70 mm to initialise the actuator.</p> |

Contacts

FACTORIES

Denmark - Headquarters
LINAK A/S
Phone: +45 73 15 15 15
Fax: +45 74 45 80 48
Fax (Sales): +45 73 15 16 13
Web: www.linak.com

China
LINAK (Shenzhen) Actuator Systems, Ltd.
Phone: +86 755 8610 6656
Phone: +86 755 8610 6990
Web: www.linak.cn

Slovakia
LINAK Slovakia s.r.o.
Phone: +421 51 7563 444
Web: www.linak.sk

Thailand
LINAK APAC Ltd.
Phone: +66 33 265 400
Web: www.linak.com

USA
LINAK U.S. Inc.
Americas Headquarters
Phone: +1 502 253 5595
Fax: +1 502 253 5596
Web: www.linak-us.com
www.linak-latinamerica.com

SUBSIDIARIES

Australia
LINAK Australia Pty. Ltd
Phone: +61 3 8796 9777
Fax: +61 3 8796 9778
E-mail: sales@linak.com.au
Web: www.linak.com.au

Austria
LINAK Zweigniederlassung - Österreich (Wien)
Phone: +43 (1) 890 7446
Fax: +43 (1) 890 744615
E-mail: info@linak.de
Web: www.linak.at - www.linak.hu

Belgium
LINAK Actuator-Systems NV/SA
(Belgium & Luxembourg)
Phone: +32 (0)9 230 01 09
E-mail: beinfo@linak.be
Web: www.linak.be - www.fr.linak.be

Brazil
LINAK Do Brasil Comércio De Atuadores Ltda.
Phone: +55 (11) 2832 7070
Fax: +55 (11) 2832 7060
E-mail: info@linak.com.br
Web: www.linak.com.br

Canada
LINAK Canada Inc.
Phone: +1 502 253 5595
Fax: +1 416 255 7720
E-mail: info@linak.ca
Web: www.linak-us.com

Czech Republic
LINAK C&S s.r.o.
Phone: +42 058 174 1814
Fax: +42 058 170 2452
E-mail: info@linak.cz
Web: www.linak.cz - www.linak.sk

Denmark - International
LINAK International
Phone: +45 73 15 15 15
E-mail: info@linak.com
Web: www.linak.com

Denmark - Sales
LINAK Danmark A/S
Phone: +45 86 80 36 11
Fax: +45 86 82 90 51
E-mail: linak@linak-silkeborg.dk
Web: www.linak.dk

Finland
LINAK OY
Phone: +358 10 841 8700
E-mail: linak@linak.fi
Web: www.linak.fi

France
LINAK France E.U.R.L
Phone: +33 (0) 2 41 36 34 34
Fax: +33 (0) 2 41 36 35 00
E-mail: linak@linak.fr
Web: www.linak.fr

Germany
LINAK GmbH
Phone: +49 6043 9655 0
Fax: +49 6043 9655 60
E-mail: info@linak.de
Web: www.linak.de

India
LINAK A/S India Liaison Office
Phone: +91 120 4531797
Fax: +91 120 4786428
E-mail: info@linak.in
Web: www.linak.in

Ireland
LINAK UK Limited (Ireland)
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
+44 (0)796 855 1606 (UK Mobile)
+35 387 634 6554 (Rep.of Ireland Mobile)
E-mail: sales@linak.co.uk
Web: www.linak.co.uk

Italy
LINAK ITALIA S.r.l.
Phone: +39 02 48 46 33 66
Fax: +39 02 48 46 82 52
E-mail: info@linak.it
Web: www.linak.it

Japan
LINAK K.K.
Phone: 81-45-533-0802
Fax: 81-45-533-0803
E-mail: linak@linak.jp
Web: www.linak.jp

Malaysia
LINAK Actuators Sdn. Bhd.
Phone: +60 4 210 6500
Fax: +60 4 226 8901
E-mail: info@linak-asia.com
Web: www.linak.my

Netherlands
LINAK Actuator-Systems B.V.
Phone: +31 76 5 42 44 40 /
+31 76 200 11 10
E-mail: info@linak.nl
Web: www.linak.nl

New Zealand
LINAK New Zealand Ltd
Phone: +64 9580 2071
Fax: +64 9580 2072
E-mail: nzsales@linak.com.au
Web: www.linak.com.au

Norway
LINAK Norge AS
Phone: +47 32 82 90 90
E-mail: info@linak.no
Web: www.linak.no

Poland
LINAK Polska
LINAK Danmark A/S (Spółka Akcyjna)
Phone: +48 22 295 09 70 /
+48 22 295 09 71
E-mail: info@linak.pl
Web: www.linak.pl

Republic of Korea
LINAK Korea Ltd.
Phone: +82 2 6231 1515
Fax: +82 2 6231 1516
E-mail: info@linak.kr
Web: www.linak.kr

Slovakia
LINAK Slovakia S.R.O.
Phone: +421 51 7563 444
Web: www.linak.sk

Spain
LINAK Actuadores, S.L.u
Phone: +34 93 588 27 77
Fax: +34 93 588 27 85
E-mail: esma@linak.es
Web: www.linak.es

Sweden
LINAK Scandinavia AB
Phone: +46 8 732 20 00
Fax: +46 8 732 20 50
E-mail: info@linak.se
Web: www.linak.se

Switzerland
LINAK AG
Phone: +41 43 388 31 88
E-mail: info@linak.ch
Web: www.linak.ch - www.fr.linak.ch
www.it.linak.ch

Taiwan
LINAK (Shenzhen) Actuator systems Ltd.
Taiwan Representative office
Phone: +886 2 272 90068
Fax: +886 2 272 90096
E-mail: sales@linak.com.tw
Web: www.linak.com.tw

Turkey
LINAK İth. İhr. San. ve Tic. A.Ş.
Phone: +90 312 4726338
Fax: +90 312 4726635
E-mail: info@linak.com.tr
Web: www.linak.com.tr

United Kingdom
LINAK UK Limited
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
E-mail: sales@linak.co.uk
Web: www.linak.co.uk

DISTRIBUTORS

Argentina
Novotec Argentina SRL
Phone: 011-4303-8989 / 8900
Fax: 011-4032-0184
E-mail: info@novotecargentina.com
Web: www.novotecargentina.com

Colombia
MEM Ltda
Phone: +[57] (1) 334-7666
Fax: +[57] (1) 282-1684
E-mail: servicioalcliente@memltda.com.co
Web: www.mem.net.co

India
Mechatronics Control Equipments India Pvt Ltd
Phone: +91-44-28558484, 85
E-mail: bala@mechatronicscontrol.com
Web: www.mechatronicscontrol.com

Indonesia
PT. Himalaya Everest Jaya
Phone: +6 221 544 8956 /+6 221 544 8965
Fax: +6 221 619 1925
Fax (Sales): +6 221 619 4658
E-mail: hejplastic-div@centrin.net.id
Web: www.hej.co.id

Israel
NetivTech LTD
Phone: +972 55-2266-535
Fax: +972 2-9900-560
Email: info@NetivTech.com
Web: www.netivtech.com

Singapore
Servo Dynamics Pte Ltd
Phone: +65 6844 0288
Fax: +65 6844 0070
E-mail: servodynamics@servo.com.sg

South Africa
Industrial Specialised Applications CC
Phone: +27 011 466 0346
E-mail: gartht@isagroup.co.za
Web: www.isaza.co.za

United Arab Emirates
Mechatronics
Phone: +971 4 267 4311
Fax: +971 4 267 4312
E-mail: mechtron@emirates.net.ae