



Actuator LA18 IC Advanced User manual

Contents

Preface	3
Valid for	4
Important information	5
Safety instructions.....	5
Safety issues	6
Before installation, re-installation or troubleshooting	7
Before start-up	7
During operation.....	7
Misc.	7
Only for EU markets	8
Only for Non EU markets	8
Misuse	8
Repairs	9
Manufacturer's declaration	9
Misc. on the HOMELINE® system	10
Warranty.....	10
Maintenance.....	10
ETL-marking	11
System overviews	12
Bluetooth® communication	13
How to mount the locking device	14
Disposal of LINAK's products	15
Main groups of disposal	15
Disposal of batteries	15
Labels	16
Drawings	17
Addresses	24

Preface

Dear User,

We are delighted that you have chosen a product from LINAK®.

LINAK systems are high-tech products based on many years of experience in the manufacture and development of actuators, electric control boxes, controls and chargers.

This User Manual does not address the end-user. It is intended as a source of information for the manufacturer of the equipment or system only, and it will tell you how to install, use and maintain your LINAK electronics. It is the responsibility of the manufacturer of the end-use product to provide a User Manual where relevant safety information from this manual is passed on to the end-user.

We are sure that your LINAK product/system will give you many years of problem-free operation.

Before our products leave the factory they undergo full function and quality testing. Should you nevertheless experience problems with your LINAK product/system, you are always welcome to contact your local dealer. LINAK subsidiaries and some distributors situated all over the world have authorised service centres, which are always ready to help you.

LINAK provides a limited warranty on its products. This warranty is, however, subject to correct use in accordance with the specifications, maintenance being done correctly, and any repairs being carried out at a service centre, which is authorised to repair LINAK products. You can review the full terms of the LINAK warranty on the LINAK website www.linak.com/warranty.

Changes in installation and use of LINAK products/systems can affect their operation and durability. The products are not to be opened by unauthorised personnel.

The User Manual has been written based on our present technical knowledge. We are constantly working on updating the information and we therefore reserve the right to carry out technical modifications.

LINAK A/S

Valid for:

This User Manual is valid for the following products:

(See the first 3 - 5 characters on the label)

Actuators:	LA18 IC Advanced Master and a LA18 IC Advanced Follower
Power supply:	SMPS001, SMPS002 or SMPS006
Controls:	HC20 Wireless, HC30 Wireless or HC40 Advanced
Accessories:	LEDLIGHTRAIL001, LEDLIGHTRAIL002, and massage motors MD1000D7 and MD1000D8

Important information

Important information on LINAK® products can be found under the following headings:



Warning!

Failure to comply with these instructions may result in accidents involving serious personal injury.



Failing to follow these instructions can result in the product being damaged or being destroyed.

Safety instruction



General

Safe use of the system is possible only when the operating instructions are read completely and the instructions contained are strictly observed.

Failure to comply with instructions marked with the "NOTE" symbol may result in serious damage to the system or one of its components.



It is important for everyone who is to connect, install, or use the systems to have the necessary information and access to this User Manual. Follow the instructions for mounting – risk of injury if these instructions are not followed.



The appliance is not intended for use by young children or infirm persons without supervision.



If there is visible damage on the product it must not be installed.



Note that during construction of applications, in which the actuator is to be fitted, there must be no possibility of personal injury, for example the squeezing of fingers or arms.



Only the power supply type SMPS001, SMPS002 or SMPS006, shall be used with the system.

The power supply shall not be covered while operating to allow sufficient cooling of this appliance.



Assure free space for movement of application in both directions to avoid blockade.



The appliance is only to be used with the power supply unit provided with the appliance.

Safety issues



The builder of the equipment shall ensure that the use of the component complies with relevant standards – like the Machine Directive. Care must be taken to avoid squeezing of cables as it can cause movement of the system!



The SMPS001/002/006 must not be packed in heat insulating material, but must be placed so that it can emit waste heat to the surroundings. There are no ventilation holes to consider, the SMPS emits heat through its surface.



Only the power supply type SMPS001, SMPS002 or SMPS006, shall be used with the system.

Before installation, re-installation, or troubleshooting

- Stop the actuators
- Pull out the mains plug.
- Relieve the actuators of any loads, which may be released during the work.

Before start-up

- Make sure that the system has been installed as instructed in this User Manual.
- Make sure that the voltage of the actuator system/SMPS is correct before the system is connected to the mains.
- System connection. The individual parts must be connected before the actuator system/SMPS is connected to the mains. See the User Manual for LINAK actuators, if necessary.

During operation

- If the actuator system makes unusual noise or smells, switch off the mains voltage immediately.
- Take care that the cables are not damaged.
- The products must only be used in an environment, that corresponds to their IP protection.

Misc.

Updated manuals and declarations can always be found here:
www.linak.com/homeline

Only for EU markets



This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.



Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Only for Non EU markets



Persons who do not have the necessary experience or knowledge of the product/products must not use the product/products. Besides, persons with reduced physical, sensory or mental abilities must not use the product/products, unless they are under surveillance or they have been thoroughly instructed in the use of the apparatus by a person who is responsible for the safety of these persons.



Moreover, children must be under surveillance to ensure that they do not play with the product.

Misuse



Do not overload the actuators – this can cause danger of personal injury and damage to the system.



When the actuator is in fully retracted position, the load on the actuator must not exceed specified max. self-lock.



Do not use the system in environments other than the intended indoor use

Repairs

Repairs In order to avoid the risk of malfunction, all HOMELINE® repairs must only be carried out by authorised LINAK service centres or repairers, as special tools must be used and special gaskets must be fitted. Products under warranty must also be returned to authorised LINAK service centres.

Further information on LINAK HOMELINE warranty can be found on the LINAK website www.linak.com/warranty.



Warning!

If any of the HOMELINE® products are opened, there will be a risk of subsequent malfunction.



Warning!

The HOMELINE® systems are not resistant to cutting oil.

Manufacturer’s declaration

**DECLARATION OF INCORPORATION OF PARTLY COMPLETED MACHINERY
2006/42/EC ANNEX II B**

LINAK A/S
Smedevænget 8
DK - 6430 Nordborg

Herewith declares that LINAK HOMELINE® products as characterized by the following models and types:

Control Boxes	CB9H, CBH Advanced, CBH Basic
Linear Actuators	LA27, LA29, LA31 HOMELINE
Dual Actuators	TD3, TD4, TD5
Controls	HB10 RF, HB20RF, HB60, HC10, HC10RF, HC20RF, HC40
Accessories	Bluetooth Adapter, DC CONNECTOR, LED Lightbox, Lightplug001, Massage Motor, SMPS001, SMPS001, SMPS002, SMPS006

comply with the following parts of the Machinery Directive 2006/42/EC, ANNEX I, *Essential health and safety requirements relating to the design and construction of machinery*:

1.5.1 Electricity supply

The relevant technical documentation is compiled in accordance with part B of Annex VII and that this documentation or part hereof will be transmitted by post or electronically to a reasoned request by the national authorities.

This partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC where appropriate.

Nordborg, 2019-10-21

LINAK A/S
John Kling, B.Sc.E.E.
Regulatory Affairs Manager
Authorized to compile the relevant technical documentation

Original Declaration

The RoHS mark is only applicable for the end product. Therefore, it must be obtained by the manufacturer of the end products. LINAK® can, however, supply the required material information on our products.

For more information, visit: <https://www.linak.com/about/declarations/>

or contact: chemicalcompliance@linak.com

Declaration of conformity

DECLARATION OF CONFORMITY

LINAK A/S
Smedevænget 8
DK - 6430 Nordborg

Herewith declares that LINAK DESKLINE® products as characterized by the following models and types:

LA18: 18040aaa0C0b0B10-deA11fffggh00

(Where - aaa can be between 36 and 300; b can be 0 or K; - d can be 1 or 6; e can be 1 or 2; fff can be between 218 and 370; gg can be A1, A2, A3, B1, B3, B5, S2 or S4; h can be 0, C or X)

Complies with RED Directive: 2014/53/EU according to following standards:
EN 62479:2010, EN 62368-1:2014/A11:2017, ETSI EN 301 489-1 V2.2.3 (2019-11), Draft ETSI EN 301 489-17 V3.2.2 (2019-12) and ETSI EN 300 328 V2.2.2 (2019-07)

Complies with RoHS2 Directive 2011/65/EU according to the standard:
EN 50581:2012

Nordborg, 2020.02-24

LINAK A/S
Dragan Macura,
Regulatory Compliance Manager
Deskline and Homeline Segments
Authorized to compile the relevant technical documentation

Original Declaration

Use the LA18 in an environment with temperature between -10 to +40 °C. Otherwise, the LA18 may be damaged. It can be operated at altitudes up to 2000 m.

Hereby, LINAK A/S declares that the radio equipment type LA18 is compliant with Directive 2014/53/EU.



Operating Frequency Range	The maximum RF Output Power
Bluetooth 2402 - 2480 MHz	7.59 dBm EIRP

Misc. on the HOMELINE® system

Warranty

This HOMELINE product is subject to warranty pursuant to the terms of LINAK HOMELINE Warranty Paper, available on the LINAK website www.linak.com/warranty

Maintenance

Clean dust and dirt on the outside of the system at appropriate intervals and inspect for damage and breaks. Inspect the connections, cables, and plugs and check for correct functioning as well as fixing points.



The cleaners and disinfectants must not be highly alkaline or acidic (pH value 6-8).

ETL-marking

Due to space limitations, the complete ETL-marking demands are not represented on the marking plates.
The full ETL Recognized Component markings are shown here.



C/N 120690
Conforms to UL962
Cert. to CSA Std. C22.2 No. 68-09
ETL Recognized Component mark for Canada and United States



C/N 9901916
Conforms to UL962
Cert. to CSA Std. C22.2 No. 68-09
ETL Recognized Component mark for Canada and United States



C/N 4008003
Conforms to UL962
Cert. to CSA Std. C22.2 No. 68-09
ETL Recognized Component mark for Canada and United States



C/N 4008005
Conforms to UL962
Cert. to CSA Std. C22.2 No. 68-09
ETL Recognized Component mark for Canada and United States




C/N 4008671
Conforms to UL962
Cert. to CSA Std. C22.2 No. 68-09
ETL Recognized Component mark for Canada and United States



C/N 4009507
Conforms to UL962
Cert. to CSA Std. No. 68-09
ETL Recognized Component mark for Canada and United States

System overviews

The LA18 IC Advanced system consists of an LA18 IC Advanced Master and an LA18 IC Advanced Follower. The system is connected to the mains via an SMP5001/002/006 and controlled by a Bluetooth® hand control (HC20 Wireless, HC30 Wireless or HC40 Advanced).



How to pair

The system features Bluetooth® Low Energy technology, which makes it capable of being controlled via the wireless LINAK® hand controls. Furthermore, it makes it possible to control the bed via the Bed Control App. However, it can only receive commands from one device at a time, so the user must wait 5 seconds without pushing a button before it is possible to use another control/mobile device.

Pairing

1. Connect the system to the mains via the connection cable.
2. The LA18 is in pairing mode for 3 minutes and the Under Bed Light flashes to indicate this.
Press the two top buttons on the hand control at the same time.



Now the light gives a long flash to indicate that the control and the LA18 are paired up. The LA18 stays in pairing mode and it is possible to connect more controls using the same procedure as above.

Note:

Wait 5 seconds after pairing control 1 before you can pair control 2. To get the system out of pairing mode – simply press any button on an already paired control.

Dual pairing

Pairing one hand control to two LA18 requires a hand control that supports dual pairing.

1. Connect the two LA18 to the mains at the same time.
 2. The Under Bed Light starts to flash to indicate pairing mode has started.
 3. Take the hand control and press the two upper buttons and both products are paired to the hand control.
- Now the light gives a long flash to indicate that the control and both the LA18 systems are paired up.

How to unpair one system

1. Put the LA18 system you want to keep paired into pairing mode and pair the hand control.
2. Send a command from the hand control and the pairing mode stops.
3. The connection between the other LA18 system and the hand control is now deleted.

Initialisation

At first time connection of the actuator, the system must be initialised. Push the “down” button on the hand control for the actuator that must be initialised. Drive the actuator to its inner position and release the button on the hand control. Now press and hold the “down” button for 10 seconds to make the LA18 initiate – the actuator can now drive outwards. If more than one actuator is connected, the same has to be done with the other channels by pressing the matching “down” button on the hand control. The system is now ready for use.


How to mount the locking device (0705889)

To ensure optimal cable relief on the SMP5001/002 a locking device (0705889) should be used. Follow the guide below on how to fix the locking device on the SMPS.


1. Take the SMPS




2. Plug the 2-poled DC cable in the SMPS



3. Slide the locking device on



4. The cable is now fully secured.



Disposal of LINAK products

As LINAK customers often ask us how our products can be disposed of or scrapped, we have prepared this guidance that enables a classification to different waste fractions for recycling or combustion.

Guidance

We recommend our products be disassembled as much as possible and divided into different waste groups for recycling or combustion.

For example, waste can be sorted into metals, plastics, cable scrap, combustible material and recoverable resources. Some of these main groups can be further divided into subgroups; e.g. metal can be divided into steel/aluminium/copper and plastic can be divided into ABS/PA/PE/PP.

As an example, the table below breaks down the different components in LINAK products to various recycling groups:

Product	Components	Recycling group
Column/ Actuator :	Spindle and motor Plastic housing Cable PC boards	Metal scrap Plastic recycling or combustion Cable scrap or combustion Electronics scrap
Control Box :	PC boards Plastic housing Cable Transformer	Electronics scrap Plastic recycling or combustion Cable scrap or combustion Metal scrap
Handset/Control :	Plastic housing Cable PC boards	Plastic recycling or combustion Cable scrap or combustion Electronics scrap

By now, almost all our casted plastic parts are supplied with an interior code for plastic types and fibre contents, if any.

Main groups of disposal

Product main groups	Metal scrap	Cable scrap	Electronics scrap	Plastic recycling or combustion	Comments
LA18 IC Advanced Master	X	X	X	X	
LA18 IC Advanced Follower	X	X	X	X	
SMPS001 / 002 / 006			X	X	
Hand controls		X	X	X	
LED Light Rail		X	X	X	

Disposal of batteries

Details regarding safe disposal of used and leaking batteries:
Batteries should be disposed in accordance with appropriate federal, state and local regulations. LINAK recommends that used or leaking batteries are disposed through local recycling system. Please do not throw used or leaking batteries in normal household waste or in nature. This will cause damage to the enviroment.

How to deal with leaking batteries

Leaking batteries should be disposed as described above.
If leaking batteries are discovered in the product, the batteries must be removed at once to minimise damage to the product. If leaking batteries are left in the product, it become defective.

It is recommended to use plastic gloves when handling leaking batteries. The contents of a leaking batteries can cause chemical burns and respiratory irritation.

If exposed to the contents of a leaking battery, please wash with soap and water. If irritation persists, please seek medical attention. In case of eye contact, please flush eyes thoroughly with water for 15 minutes and seek medical attention.

Labels

Label for LA18 IC Advanced Master

LINAK®

Designed in Denmark
DK - 6430 Nordborg

Item Name : 180401520C0K0B10-61A11483A1C00
Item No. : 180003-00
Model Type : LA18A
Prod. Date : 07/02/2020
Max Load : Push 6000 N IP20
Power Range : 18V~29V=, Max. 6.0 A
Duty Cycle : 10 %, Max. 2 min./18 min.

NOT TO BE OPENED BY UNAUTHORIZED PERSONNEL
NE PAS OUVRIR PAR DU PERSONNEL NON AUTORISÉ
W/O# 123456-0001 ASSEMBLED IN USA

R-R-LKR-LA18A

us File E151104

Label for LA18 IC Advanced Follower

LINAK®

Designed in Denmark
DK - 6430 Nordborg

Item Name : 180400920C0K0B10-61A11483B3000
Item No. : 180004-00
Model Type : LA18A
Prod. Date : 07/02/2020
Max Load : Push 6000 N IP20
Power Range : 18V~29V=, Max. 6.0 A
Duty Cycle : 10 %, Max. 2 min./18 min.

NOT TO BE OPENED BY UNAUTHORIZED PERSONNEL
NE PAS OUVRIR PAR DU PERSONNEL NON AUTORISÉ
W/O# 123456-0001 ASSEMBLED IN USA

R-R-LKR-LA18A

us File E151104

Label for SMP5001

LINAK®

DK- 6430 Nordborg

Type : Power Supply
Item No. : SMP5001
Model No. : ASW0539-24020002A
Input : 230-240V-50Hz Max1.8A
Output : 24.0V= 2.0A (continuous)
or : Max.Pout= 150W(Duty cycle:10%,2min on/18min off)
Serial No. : PO.XXXXXX CY190521

NOT TO BE OPENED BY UNAUTHORIZED PERSONNEL
NE PAS OUVRIR PAR DU PERSONNEL NON AUTORISÉ
W/O# 123456-0001 ASSEMBLED IN USA

170008-11

us File E151104

Label for SMP5002

LINAK®

DK- 6430 Nordborg

Type : Power Supply
LP Part No. : 13600039
Item No. : SMP5002
Input : 120V~, 60Hz Max2.9A
Output : 24V = 2A(Continuous)
Output : 21V = 6A (Duty cycle:10%,2min on,18min off)
Model No. : ASW0551-24020002A
Serial No. : PO.XXXXXX CY190517

NOT TO BE OPENED BY UNAUTHORIZED PERSONNEL
NE PAS OUVRIR PAR DU PERSONNEL NON AUTORISÉ
W/O# 123456-0001 ASSEMBLED IN USA

170008-11

us File E151104

Label for SMP5006

LINAK®

DK- 6430 Nordborg

Type : Power Supply
LP Part No. : 13600039
Item No. : SMP5006
Model No. : ASW0552-24020002B
Input : 100-240V~ 50/60Hz Max 2.9A
Output : 58.0V 20.0V= 2.0A(Continuous)
Input : 110V~ 50/60Hz Max 2.9A
Output : 27V = 6A(Duty cycle:10%,2min on,18min off)
Input : 230V~ 50/60Hz Max 2.9A
Output : 27V = 6A(Duty cycle:10%,2min on,18min off)
Serial No. : PO.XXXXXX CY190111

CAUTION
• Risk of electric shock
• For indoor use only
• Do not open the unit
• Dry location use only

170008-11

us File E151104

Label for LED Light Rail

LINAK®

Designed in Denmark
DK- 6430 Nordborg

Item : LEDLightRail001

ASSEMBLED IN CHINA

170008-11

us File E151104


Label for HC20 Wireless



Label for HC30 Wireless



Label for HC40 FRAME Advanced




Label for HC40 TWIST Advanced




DRAWING APPENDIX


LA18 IC Advanced Master




LA18 IC Advanced Follower (B5)






LA18 IC Advanced Master Click-on back fixture




LA18 IC Advanced Follower Click-on back fixture (B5)









HC20 Wireless




HC30 Wireless




HC40 FRAME Advanced




HC40 TWIST Advanced



LEDLIGHTRAIL001



LEDLIGHTRAIL002



LINAK APPLICATION POLICY

The purpose of the application policy is to define areas of responsibilities in relation to applying a LINAK product defined as hardware, software, technical advice, etc. related to an existing or new customer application.

LINAK products as defined above are applicable for a wide range of applications within the Medical, Furniture, Desk and Industry areas. Yet, LINAK cannot know all the conditions under which LINAK products will be installed, used, and operated, as each individual application is unique.

The suitability and functionality of the LINAK product and its performance under varying conditions (application, vibration, load, humidity, temperature, frequency, etc.) can only be verified by testing, and shall ultimately be the responsibility of the LINAK customer using any LINAK product.

LINAK shall be responsible solely that the LINAK products comply with the specifications set out by LINAK and it shall be the responsibility of the LINAK customer to ensure that the specific LINAK product can be used for the application in question.

FACTORIES

• Denmark

LINAK A/S
Group Headquarters
Tel: +45 73 15 15 15
Fax: +45 74 45 80 48
Fax (Sales): +45 73 15 16 13
www.linak.com

• Denmark

LINAK Profiles
Tel: +45 73 70 95 30
www.linak-profiles.com

• China

LINAK (Shenzhen) Actuator Systems, Ltd.
Tel: +86 755 8610 6656
Fax: +86 755 8610 6990
www.linak.cn

• Slovakia

LINAK Slovakia s.r.o.
Tel: +421 51 7563 444
Fax: +421 51 7563 410
www.linak.sk

• Thailand

LINAK APAC Ltd.
Tel: +66 33 265 400
www.linak.com

• USA

LINAK U.S. Inc.
Americas Headquarters
Tel: +1 502 253 5595
Fax: +1 502 253 5596
www.linak-us.com

SUBSIDIARIES

• Australia

LINAK Australia Pty. Ltd
Tel: +61 3 8796 9777
Fax: +61 3 8796 9778
www.linak.com.au

• Austria

LINAK Repräsentanz
Österreich (Wien)
Tel: +43 (1) 890 7446
Fax: +43 (1) 890 744615
www.linak.at - www.linak.hu

• Belgium

LINAK Benelux
(Belgium & Luxembourg)
Tel: +32 (0)9 230 01 09
www.linak.be - www.fr.linak.be

• Brazil

LINAK Do Brasil Comércio De Atuadores Ltda.
Tel: +55 (11) 2832 7070
Fax: +55 (11) 2832 7060
www.linak.com.br

• Canada

LINAK Canada Inc.
Tel: +1 502 253 5595
Fax: +1 416 255 7720
www.linak-us.com

• China

LINAK (Shenzhen) Actuator Systems, Ltd.
Tel: +86 755 8610 6656
Fax: +86 755 8610 6990
www.linak.cn

• Czech Republic

LINAK C&S s.r.o.
Tel: +42 058 174 1814
Fax: +42 058 170 2452
www.linak.cz - www.linak.sk

• Denmark - Headquarters

LINAK A/S - Group Headquarters
Tel: +45 73 15 15 15
Fax: +45 74 45 80 48
Fax (Sales): +45 73 15 16 13
www.linak.com

• Denmark - International

LINAK International
Tel: +45 73 15 15 15
www.linak.com

• Denmark - Sales

LINAK DANMARK A/S
Tel: +45 86 80 36 11
Fax: +45 86 82 90 51
www.linak.dk

• Finland

LINAK OY
Tel: +358 10 841 8700
www.linak.fi

• France

LINAK FRANCE E.U.R.L
Tel: +33 (0) 2 41 36 34 34
Fax: +33 (0) 2 41 36 35 00
www.linak.fr

• Germany

LINAK GmbH
Tel: +49 6043 9655 0
Fax: +49 6043 9655 60
www.linak.de

• India

LINAK A/S India Liaison Office
Tel: +91 120 4531797
Fax: +91 120 4786428
www.linak.in

• Ireland

LINAK UK Limited (Ireland)
Tel: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
+44 (0)796 855 1606 (UK Mobile)
+35 387 634 6554 (Republic of Ireland Mobile)
www.linak.co.uk

• Italy

LINAK ITALIA S.r.l
Tel: +39 02 48 46 33 66
Fax: +39 02 48 46 82 52
www.linak.it

• Japan

LINAK K.K.
Tel: 81-45-533-0802
Fax: 81-45-533-0803
www.linak.jp

• Malaysia

LINAK Actuators Sdn. Bhd.
Tel: +60 4 210 6500
Fax: +60 4 226 8901
www.linak.my

• Netherlands

LINAK Benelux
Tel: +31 76 5 42 44 40
www.linak.nl

• New Zealand

LINAK New Zealand Ltd
Tel: +64 9580 2071
Fax: +64 9580 2072
www.linak.com.au

• Norway

LINAK Norge AS
Tel: +47 32 82 90 90
www.linak.no

• Poland

LINAK Polska
LINAK Danmark A/S (Spółka Akcyjna)
Tel: +48 22 295 09 70/22 295 09 71
www.linak.pl

• Republic of Korea

LINAK Korea Ltd.
Tel: +82 2 6231 1515
Fax: +82 2 6231 1516
www.linak.kr

• Slovakia

LINAK Slovakia s.r.o.
Tel: +421 51 7563 444
www.linak.sk

• Spain

LINAK Actuadores, S.L.u
Tel: +34 93 588 27 77
Fax: +34 93 588 27 85
www.linak.es

• Sweden

LINAK Scandinavia AB
Tel: +46 8 732 20 00
Fax: +46 8 732 20 50
www.linak.se

• Switzerland

LINAK AG
Tel: +41 43 388 31 88
Fax: +41 43 388 31 87
www.linak.ch - www.fr.linak.ch
www.it.linak.ch

• Taiwan

LINAK (Shenzhen) Actuator systems Ltd.
Taiwan Representative office
Tel: +886 2 27290068
Fax: +886 2 27290096
www.linak.tw

• Thailand

LINAK APAC Ltd.
Tel: +66 33 265 400

• Turkey

LINAK İth. İhr. San. ve Tic. A.Ş.
Tel: +90 312 4726338
Fax: +90 312 4726635
www.linak.com.tr

• United Kingdom

LINAK UK Limited
Tel: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
www.linak.co.uk

• USA

LINAK U.S. Inc.
North and South America Headquarters
Tel: +1 502 253 5595
Fax: +1 502 253 5596
www.linak-us.com
www.linak-latinamerica.com

DISTRIBUTORS

• Argentina

NOVOTEC ARGENTINA SRL
Tel: 011-4303-8989/8900
Fax: 011-4032-0184
www.novotecargentina.com

• Colombia

MEM Ltda
Tel: +57 (1) 334-7666
Fax: +57 (1) 282-1684
www.mem.net.co

• India

Mechatronics Control Equipments India Pvt Ltd
Tel: +91-44-28558484, 85
www.mechatronicscontrol.com

• Indonesia

PT. HIMALAYA EVEREST JAYA
Tel: +6 221 544 8956/221 549 8965
Fax: +6 221 619 1925
Fax (Sales): +6 221 619 4658
www.hej.co.id

• Iraq

Scan Medical Tech
Tel: +964 770 470 2202

• Israel

NetivTech LTD
Tel: +972 55-2266-535
Fax: +972 2-9900-560
www.netivtech.com

• Kingdom of Bahrain

Mechatronics Industrial Equipments
Tel: +973 17280059
Fax: +973 17910045
www.mechatronicsbh.com

• Qatar

Mechatronics Industrial Equipments
Tel: +974 44581155
Fax: +974 44689135
www.mechatronicsqatar.com

• Singapore

Servo Dynamics Pte Ltd
Tel: +65 6844 0288
Fax (Sales): +65 6844 0070

• South Africa

Industrial Specialised Applications CC
Tel: +27 011 466 0346
www.isaza.co.za

• United Arab Emirates

Mechatronics Industrial Equipments LLC
Tel: +971 4 267 4311
Fax: +971 4 267 4312
www.mechatronics.ae

LINAK® accepts no responsibility for possible errors or inaccuracies in catalogues, brochures, and other material. LINAK reserves the right to change its products without prior notice. LINAK cannot guarantee product availability and reserves the right to discontinue the sale of any product. The user is responsible for determining the suitability of LINAK products for a specific application. All sales are subject to the 'Standard Terms of Sale and Delivery', available on LINAK websites.

LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.



WE IMPROVE YOUR LIFE